


*Schwenger*

# **Instruction Manual**



**Sedan and  
Convertible**

**January 1961 Edition**

***Instruction Manual***

---

***Sedan and Convertible***

VOLKSWAGENWERK AG · WOLFSBURG · GERMANY



Introduction . . . . .	5
Controls and Instruments . . . . .	6
Operating Instructions . . . . .	9
Practical Driving . . . . .	26
Cold Weather Hints . . . . .	32
Lubrication . . . . .	35
Wheels and Tires . . . . .	44
Care of the Car . . . . .	47
Maintenance . . . . .	53
General Description . . . . .	75
Technical Data . . . . .	78
Bulb Chart . . . . .	81
Lubrication Chart . . . . .	83
Maintenance Chart . . . . .	84
Index . . . . .	85
Sectional View of Volkswagen . . . . .	88
Tools and Accessories . . . . .	inside back page



**W**e are sure that the excellent performance and economical operation of your Volkswagen will justify the confidence you placed in our firm when purchasing this car.

This Manual sets out in full the information necessary for the proper operation, care and general maintenance of your car. In addition, interesting specification details have been included to familiarize you with the construction and mechanical details of this fine piece of mechanism.

No effort has been spared to produce an efficient and reliable automobile. This Instruction Manual can help you obtain lasting satisfaction in the operation of your VW. All information contained in this handbook is based on the actual experience of many years.

In order to maintain maximum efficiency, we particularly stress the importance of following the recommendations set out in this manual. The intimate knowledge obtained by studying this Manual will assure you of the utmost service and satisfaction from your VOLKSWAGEN.

Regular attention to proper lubrication and maintenance of your car is important. An extensive network of VW Dealers exists throughout the world, and you will readily recognize such stations by the familiar blue VW SERVICE sign.


These Dealers are in constant contact with the Volkswagenwerk through our field engineers, thus providing skillful and speedy execution of any job to be done. You'll enjoy many more miles of trouble-free driving by giving your VW just ordinary care.

All experienced car owners know the value of preventive maintenance. The efforts in regard to care and maintenance will be amply rewarded in the long run.

Happy motoring

**VOLKSWAGENWERK AG**

# CONTROLS AND INSTRUMENTS






## The first thing

you must do is become familiar with the controls and instruments of your new VOLKSWAGEN. Sit behind the wheel, make yourself comfortable, and get acquainted with all the various levers, switches, and controls. Some of the features you may already know. Check your present knowledge against this complete list.


<b>INSTRUMENTS:</b>	Speedometer . . . . .	5
	Warning light – Blue – Headlight high beam	7
	Warning light – Red – Generator and cooling	4
	Warning light – Green – Low oil pressure . . .	8
	Warning light – Red – Flashing indicators (dual arrow) . . . . .	6
<b>FOOT CONTROLS:</b>	Headlight dimmer switch . . . . .	17
	Clutch pedal . . . . .	18
	Brake pedal . . . . .	19
	Accelerator pedal . . . . .	20
	Fuel tap . . . . .	21
<b>HAND CONTROLS:</b>	Combined ignition and starting switch . . . . .	9
	Headlight and instrument light switch . . . . .	10
	Windshield wiper and washer switch . . . . .	12
	Gear lever . . . . .	24
	Hand brake lever . . . . .	22
	Heating control . . . . .	23
	Horn half ring . . . . .	16
	Flashing indicator lever . . . . .	3
	Front hood lock control . . . . .	15
	Inside door handle . . . . .	13
	Window regulator handle . . . . .	14
	Vent wing handle release button . . . . .	2
	Vent wing handle . . . . .	1
	Ash tray . . . . .	11

Among the papers which come with your car you will find details regarding the model, year of construction, and chassis and engine numbers. The Police or Traffic Department will check as to whether the information on the papers is identical with that on your car.




**The Identification Plate**

is found behind the spare wheel, underneath the front hood.



**The Chassis Number**

is found on the backbone of the chassis, underneath the rear seat.



**The Engine Number**

is on the crankcase flange for the generator support.

**Only one Key**

is required to unlock the door, switch on the ignition, and operate the starting motor. It is suggested that you record the key number so that you can order a duplicate from your dealer, in case you lose or misplace the key.


# OPERATING INSTRUCTIONS

Before you drive away please check

**engine oil level**



**fan belt tension**



**quantity of fuel in the tank**



**tire pressures**



**efficiency of brakes**




**position of driving mirrors**



and, if driving in fog or at night,

**the exterior lights**



### Engine Oil Level

The oil level should be checked with the engine at rest. The oil level is satisfactory when it is between the two marks on the oil dipstick, but it should never be permitted to drop below the lower mark. To make an accurate check, it is best to wipe the dipstick with a clean rag beforehand. Should it become necessary to add oil please remember the following hints: Most oils marketed at present contain chemical ingredients to improve their lubricating qualities. However, oils of different origin behave differently when used as engine lubricants and should, therefore, not be mixed.

**Select an HD oil from among the well-known and dependable brands right at the beginning, and stick to it**

Further hints regarding engine oil changes are given in the sections "Cold Weather Hints" and "Lubrication" on pages 32 and 35-37.

### Fan Belt


The V-belt drives the generator and the engine fan. **Perfect condition and correct tension of the belt insure its long life and adequate cooling of the engine.**

Checking is very simple:

The belt, when pressed with the thumb at mid-point, should yield:

$$a = 1.5 \text{ cm. (.6")}$$

If you find any signs of wear, such as frayed edges, see your VW Dealer.



Even though the belt, when properly tensioned, has a long service life, a spare should always be carried to meet any emergency.


The adjustment or replacement of the fan belt is described on page 54.

## Fuel Tank

The tank has a capacity of 40 liters (10.6 U.S. gall., 8.8 Imp. gall.), sufficient for well over 500 kilometers (300 miles). Under normal conditions, the fuel tap should be set at position "1", while the car is in use. If the engine begins to "stutter", due to lack of fuel, just turn the tap to "2". A fuel reserve of 5 liters (1.3 U.S. gall., 1.1 Imp. gall.) will then last for about a further 60 kilometers (37 miles). It is important to re-set the tap at position "1" when refilling the tank, otherwise there will be danger of running out of fuel on the road. The fuel supply is shut off when the lever is set half way (45°) between the two positions.

Positions of fuel tap:

- 1 — Open
- 2 — Reserve
- 3 — Shut off



The VW Engine runs on all reputable fuels. Suitable fuels, including gasoline-benzol blends, have such characteristics as constant physical properties, sufficient anti-knock qualities and freedom from harmful ingredients.

**The selection of a particular grade and brand of fuel is therefore left entirely to your discretion.**

## The Tires

deserve and require your special attention. A special section deals with the care of the tires on pages 44-46. The riding comfort and the road-holding of your VOLKSWAGEN will greatly depend on their condition. Maintaining correct tire pressures and avoiding driving abuses are the most important factors in obtaining maximum tire life. Check, at least once a week, using a reliable tire gauge that the tires are correctly inflated.



Here are the recommended pressures:

High speed driving conditions on long trips:

**front 1.2 kg./sq. cm. (17 lbs./sq. in.)**

**rear 1.6 kg./sq. cm. (23 lbs./sq. in.)**

Normal conditions:

Car occupied by 1 or 2 persons

**front 1.1 kg./sq. cm. (16 lbs./sq. in.)**

**rear 1.4 kg./sq. cm. (20 lbs./sq. in.)**

Car occupied by 3 to 5 persons

**front 1.2 kg./sq. cm. (17 lbs./sq. in.)**

**rear 1.6 kg./sq. cm. (23 lbs./sq. in.)**

### **The Brakes**

should be checked while the car is in motion before starting out on a trip to make sure they are in good working order.

The section "Apply the brakes gently" on page 17 deals with the correct application of brakes under various circumstances.

### **Good Exterior Lights**

are the first requirement of safe use at night. The three positions of the light switch are as follows:

- 1 - Fully pushed in                      - Off
- 2 - Pulled out to first stop - Parking light, tail and license plate lights
- 3 - Fully pulled out                      - Headlight upper or lower beams (depending on position of foot dimmer switch), tail and license plate lights.

When pulling out the lighting switch knob to either the first or second stop, the instrument light is automatically turned on. By turning the knob, a variable degree of instrument lighting is obtained, turning the knob to extreme left turns out the light entirely.

When checking the lighting system, do not forget the two stop lights which should light up when depressing the brake pedal with the ignition turned on.

## Starting the Engine

is easy, because you are now familiar with the various controls and instruments. However, make sure that the gear lever is in neutral before starting the engine.

The ignition key starting enables you to start the engine by merely turning the key. First the ignition is switched on by turning the key to the right. The red generator warning light and the green light for the oil pressure will light up. **When the ignition has been switched on the starter must be operated at once.** Turn the key further to the right until the stop is reached.

As soon as the engine fires, release pressure on key to switch off starting motor.

If the engine does not start the first time another attempt can be made after the ignition has been switched off and on again. A safety lock in the starter-ignition switch prevents the starter from being operated repeatedly when the ignition is on and thus being damaged by the engine when it is running.



**Important.** In cold weather the transmission oil is apt to congeal. It is, therefore, good practice to declutch until the engine starts. Thus you will save the battery and facilitate the operation of the starting motor. The engine oil also becomes thick so do not race the engine when starting from cold. You will never encounter any difficulties when starting your engine in the coldest weather, if you observe the rule of using the specified light grade engine and transmission oils.

### **At temperatures below freezing point**

and when the engine is cold it is only necessary to depress the accelerator pedal fully and then release it before switching on the ignition and operating the starter.

If the engine does not start within the first 10 seconds the operation can be repeated several times. Bear in mind, however, that continued starter operation places a great strain on the battery and pauses should be made to allow the battery to recover. The starting procedure should not be interrupted if the engine is heard to fire a few times without starting.


Once started, you can drive off straight away as the automatic choke regulates the mixture and the idling speed and opens automatically as the engine warms up.

### **At temperatures above freezing point**

or when the engine is still warm depress the accelerator pedal slowly, without pumping up and down, while operating the starter. It is important for you to know that unnecessary accelerator pedal pumping makes it difficult to start a warm engine and increases fuel consumption when driving.

### **Caution**

**Be careful when starting the engine inside your garage. Keep the door and windows open so that the exhaust fumes can escape. These contain deadly carbon monoxide which is a colorless, tasteless and odorless gas.**




### **The Air Cleaner**

The air drawn in by the engine enters the air cleaner through a pipe which is fitted with a swinging valve with a balance weight. The valve opens and closes according to the speed of the engine and regulates the intake of pre-heated air.



At temperatures over 20° C (68° F) the valve must be fixed in the open position by means of the clip.



### Driving Off

is extremely easy, if you observe the following points:

- 1 - **Depress the clutch pedal as far as possible. Keep it in that position.**
- 2 - **Shift to the first gear. Release the hand brake.**
- 3 - **Engage the clutch by allowing the pedal to return slowly, and simultaneously depressing the accelerator pedal. The car will start to move forward.**
- 4 - **Gradually increase the pressure on the accelerator pedal and remove your foot from the clutch pedal, as the clutch is now fully engaged.**

Shifting to second gear is equally simple

- 1 - **Take your foot off the accelerator pedal, simultaneously depressing the clutch pedal.**
- 2 - **Shift gear lever into second position.**
- 3 - **Engage the clutch gently by gradually taking your foot off the pedal, and at the same time depressing the accelerator pedal.**

You now know how to "shift gears", and may at will shift to third and fourth positions. As you have now read the accelerator and clutch pedals are operated simultaneously, but in opposite directions. It is the coordination of these simultaneous operations that brings skill in shifting gears.

To shift to **reverse gear** which should be done only when the vehicle is stationary, first depress the gear lever and then move it to the left and to the rear. A locking device prevents unintentional shifting.

### **Shifting to a Lower Gear**

This is what you should do in dense city traffic, or with sharp turns ahead of you, or when driving uphill.

- 1 - Release accelerator pedal and depress clutch pedal.**
- 2 - Shift to the next lower gear.**
- 3 - Release clutch pedal and depress accelerator pedal simultaneously.**

Of course, this takes less time to do than it does to describe. We do not want to bore you with a technical discourse, but it may be of interest to you to know that, when changing down, the synchromesh device ensures quiet meshing of the gears, as the lower gear is synchronized so that both gears are turning at the same speed.

When shifting gears, it is absolutely necessary to depress the clutch pedal fully. Incomplete declutching makes gear shifting difficult and leads to rapid wear of the synchronizer stop rings.

In order to save transmission and engine from damage shift down from

- 4th to 3rd between 75 and 40 k. p. h. (45 and 25 m. p. h.)**
- 3rd to 2nd between 50 and 25 k. p. h. (30 and 15 m. p. h.) only.**

The 1st gear is only used for moving off, driving at walking pace, or on very steep inclines.

After a little practice, you will take pleasure in the correct handling and shifting of the gears and obtain the utmost satisfaction from the efficient performance of your new VOLKSWAGEN. Under no circumstances should you be afraid to shift to a lower gear, or try to avoid shifting by merely "slipping" (partly disengaging) the clutch.

## **Apply the brakes gently**

The brake responds to even the slightest foot pressure. Increasing pressure will slow the car down progressively. However, avoid locking the wheels. Locked wheels will not shorten the braking distance but may cause you to lose control over the movement of the vehicle and will affect the tires adversely.

Here are a few rules on correct braking:

### **Use your brakes before, not while making a turn**

It is neither good practice nor is it economical to shift to a lower gear far ahead of a turn. Do not hesitate to use the brakes and to shift only shortly before entering the curve so that you may already accelerate again while still negotiating it.

To jam on the brakes suddenly can only be justified when danger is ahead. Nevertheless, it is necessary to check full braking capacity at certain intervals so that you will be familiar with the behaviour of the car and with the actual braking distance should sudden braking become necessary. Before carrying out the test, look into the rear view mirror to make sure that you will not endanger any vehicle that might be following you.

Operate the brakes especially gently when the road is wet or covered with ice. Sudden braking of the wheels will cause the car to skid.

**When driving downhill**, make use of the braking capacity of the engine compression by shifting to that gear which you would use in driving uphill.

You will save and preserve the brakes if you use them only to control the speed occasionally, and at the same time you will attain a higher degree of safety. The ignition must never be switched off when going downhill.

## **Stopping the Car**

Take your foot off the accelerator pedal and apply the brakes gently. Shortly before the car comes to a full stop, depress the clutch pedal, place the gear lever in neutral position and release clutch pedal again. The engine continues to idle. If you wish to stop the engine, just turn the ignition key to the left.

## The Front Seats

can be adjusted to suit individual requirements. Merely raise the adjusting lever and slide the seat either backward or forward to the most convenient position. The seat rises as it moves forward, enabling short persons to sit higher.



1 — normal    2 — backward    3 — forward

The rake of the front seat backs can be set at three positions by turning a lever.

## Sitting Comfortably

Sitting and driving for long periods can place a certain amount of strain on the human body. It is therefore important to adjust the seat correctly to your individual requirements, and so avoid unnecessary fatigue.

Make use of the whole of the seat area by sitting well up against the back rest, thus giving yourself a maximum area of support for the legs.

Firstly adjust the rake of the seat back to the normal position. Aim at an easy, relaxed position. The whole of the back should be evenly and comfortably supported. The head should be held erect to avoid neck strain. Then slide your seat horizontally to the position where pedals, gear shift and brake lever can most conveniently be reached.

But even in the correct posture, without moving, long hours at the wheel can prove tiring, and you will soon find out how useful it is to change position from time to time.

For instance, try shifting the weight of your body away from the center, to the left or right. Change the position of your legs and feet and alter your grip on the steering wheel. The rake of the seat back can be adjusted forwards or backwards according to visibility and traffic conditions. Always make sure, however, that your back is properly and comfortably supported.



Right

wrong

wrong

It is also a mistake to bend too far forward at the hips, with your spine away from the seat back. This causes back-ache and cramps the waist and the legs.

Often too, the driver tends to slide too far forward in his seat with the result that the lower part of the back is unsupported, and the spine bent at an unnatural angle. In this position the normal motion of the car will soon become tiring, for the further forward you slide in your seat, the more awkward does your posture become and the less support will there be for your legs.

If you lean back too far, the head has to be held at an unnatural angle and the arms stretched awkwardly forward. This results in strain and fatigue in neck and shoulder muscles.

### Both Hands

should be kept on the steering wheel, in an easy, natural position affording maximum control – as shown here, for instance.



### The Interior Light

is automatically operated by opening or closing either of the doors.

As an added convenience, the lamp may be operated by the manually operated three-position switch incorporated in the lamp fitting.

Positions of switch knob:

- Lower – On
- Intermediate – Off
- Upper – Door contacts

This allows the light to be turned off with the doors open.

The Convertible is equipped with a three-position tumbler switch below the instrument panel:

- Rear – On
- Intermediate – Off
- Forward – Door contacts



### The Ash Tray

below the instrument panel can be completely pulled out for emptying by slightly depressing the retaining spring.

To remove the rear ash tray lift the retaining spring. To reinstall, insert the tongue at the bottom of the tray into the slot of the ash tray frame.



## The Windshield Wipers



operate immediately when the knob is turned fully to the right. The wipers are self-parking.

If the knob is pulled outward, the windshield washer sprays water onto the windshield. This operation may be continued until the windshield is perfectly clean.

Make a practice of using the wipers only when the windshield is wet. The risk of scratches on the glass is thereby avoided.


- 1 - Windshield wiper on
- 2 - Windshield wiper off
- 3 - Windshield washer on

The container which holds 1 liter is mounted under the front hood behind the spare wheel. Do not forget to refill the container from time to time. In winter add 25% pure spirit to the water to prevent its freezing at least up to  $-12^{\circ}\text{C}$  ( $+10^{\circ}\text{F}$ ).



## The Rear Seat Back



is held in place by a detachable rubber strap. Unhook the strap to tilt the seat back rest forward for loading or unloading luggage.



### **The Control Knob**

for the front hood latch of the Convertible is equipped with a lock as an additional theft precaution. Thus, luggage, fuel and spare wheel are well protected with the top lowered. The key – which also serves for locking the door and operating the combined ignition and starting switch – should be turned anti-clockwise and removed immediately after the control knob has been pulled out. When closing the front hood, the control knob and the hood latch are locked automatically.

A different key is provided for the glove compartment lock on Convertibles.



### **The Jack**

is secured in position adjacent to the spare wheel by means of a quick release clamping strap. Also accommodated under the front hood are the tools and the spare fan belt.

### **The Sun Roof**

is free to slide when the locking lever is turned to the left. It may be fixed in any desired position by merely twisting the lever to the right. It is good practice, however, to open the roof fully prior to sliding it to the desired position. This will not only make the opened roof look better, but will also





fold the material properly. To close the sun roof, place the locking lever to the left, slide the roof forward until the locking hook engages in the opening, and return the locking lever firmly to the right.

### **Misted Windows**

can greatly obstruct visibility on all sides. This is brought about by the humidity from the passengers' breath in the car and a low outside temperature. By using the vent windows intelligently sufficient fresh air can be provided while the used air is sucked out. Not only will the windows remain clear but so will your head.

### **The Convertible Top**


can easily be lowered and raised by one person. The service life of the top largely depends on the way the top is lowered and raised. That is why we would particularly stress the importance of the following recommendations.




### **To Lower the Top**

- 1 - Pull the two clamps above the windshield downward to unfasten the top (A).
- 2 - Raise the headers slightly and fold back the top.

3 - Withdraw top cover from the linkages on both sides (B).



4 - Push the top lining inward so that the linkages are free (C).



5 - Press down the top until the springloaded catches (one on each side) engage in the slots cut in the side rails (E).

6 - Place the caps of the top clamps over the header guides and press down the levers (D).



7 - Taking particular care with the lower part, install the protective boot and secure it with the snap fasteners over the folded top cover which should be completely concealed except for the ornamental edge which remains visible.

### **To Raise the Top**

- 1 – Unsnap the fasteners of the protective boot and remove. It can best be stored in one of the two luggage compartments.
- 2 – Raise the clamp levers.
- 3 – Press down the top and disengage the catches.
- 4 – Raise the top.
- 5 – Pull the top down until the header guides have entered the channels above the windshield frame.
- 6 – Place the clamp caps over the noses of the brackets and turn up the levers.





## PRACTICAL DRIVING

### **Breaking-in (running-in) Period**

does not imply inconvenience as your Volkswagen needs no "breaking-in". Progressive refinements have raised the VW engine to its present predominant position and it is these refinements which allow an omission of breaking-in instructions. Your car may be operated right from the beginning at the full speeds recommended for the gears.

1st gear

**1st gear 0- 25 k.p.h. ( 0-15 m.p.h.)**

**2nd gear 10- 50 k.p.h. ( 6-30 m.p.h.)**

**3rd gear 25- 75 k.p.h. (15-45 m.p.h.)**

**Top gear 40-115 k.p.h. (25-72 m.p.h.)**



**The life of your car, its performance, and its operation will depend on your driving habits.**

Maximum satisfaction in the running of your car will be assured by following the fundamental rules for driving an automobile:

**Do not race the engine unnecessarily no matter whether the car is stationary or in motion.**

The new engine is not governed. It is good practice therefore, to glance at the speedometer from time to time.

**Do not allow the engine to labor in any gear.**

Don't think that low revolutions will promote the life of your new engine.


**When driving uphill**

always change gear as soon as the speed drops and the speedometer reading drops to the maximum speed limit of the next lower gear. Never allow the engine to labor in 4th gear, which is nearly an overdrive.

**Economical operation**

is one of the outstanding features of your car. However, getting a few extra miles from each gallon depends on the manner in which you handle the car and use the gears.


2nd gear



3rd gear



4th gear



**When accelerating,**


press on the accelerator pedal slowly and only to such an extent as is necessary for reaching the desired speed. Depressing the accelerator pedal rapidly does not improve acceleration, but results in an increased fuel consumption.

**Do not "pump" the accelerator pedal**

unless circumstances require it. Even the small quantity of fuel additionally discharged by the accelerator pump each time the accelerator pedal is depressed results in a marked increase in the overall fuel consumption.

## Drive your car smoothly and to suit the circumstances

both when in city traffic and on main roads. Adapt the speed of the car to prevailing road and traffic conditions. A good driver accelerates gradually, slows down in time, and utilizes the braking power of the engine. Make use of the full acceleration capacity and the excellent brakes of your car only when you really need to.



## How to drive at high speed without sacrificing fuel economy

When you have accelerated to the desired speed, slowly let the accelerator pedal return to the position which just maintains this speed. This practice is especially economical when driving on highways. If you attach particular importance to economy and also to a fair average speed, you will be well advised to select a suitable cruising speed in the most efficient range of consumption. The chart illustrates the manner in which fuel consumption increases in relation to the speed; it increases more rapidly at higher speeds.

Perhaps you are aware of the fact that air resistance is an obstacle for all highspeed vehicles. Due to the simple and sweeping lines of your VOLKSWAGEN, air resistance is relatively low, but it should be remembered that high road speed always involves a greater fuel consumption.

## Watch the Road

closely while driving. As to using the various levers, switches and controls, you now are able to operate them automatically. Furthermore, your VOLKSWAGEN will "tell" you on its own accord when it needs attention.

### Headlights

The high beam of your headlights can be blinding to oncoming drivers. You know yourself how unpleasant and dangerous this is. For this reason, be considerate! The blue light will tell you when the high beam is switched on. Just step on the dimmer switch to transfer the headlights from upper to lower beam.

### Generator and Cooling

are controlled simultaneously by a red light. The light will show when the ignition is turned on and when the engine is running at low speed. The light should go out when speed is increased.

**Important.** If the red light comes on while you are driving the car, the fan belt may be broken. Bring your car to a stop, and find out what is wrong, for if the belt is broken, the cooling is disrupted and the generator no longer charges.

### Oil Pressure

The oil pressure of your car is as important as the oil level, which you have already checked. When the ignition is turned on, the Green Oil Pressure Light will go on. The light should go out when the engine is started and the oil pressure increases.

**Important.** If the green light goes on with the engine running, the chances are that the oil circulation has been interrupted, which means that the lubrication of the engine has ceased. Stop at once and check the level of the oil before you consult a Service Station. An occasional flashing of the lamp with the engine warm and at low speed does not indicate trouble, if the light goes off again as the speed increases.

### Flashing Indicators


The direction indicators lie outside the driver's vision. However, the red light will show you when the indicator is in operation. The direction indicator switch which is self-cancelling can be operated without taking the hand off the steering wheel.

### Blue Light

### Red Light

### Green Light

### Red Arrows



### **Safety First**

Safety for yourself, and safety for others, this is what counts most! Your VOLKSWAGEN is a car that "hugs" the road in an excellent way, and does not roll when taking a turn. Your car has an extraordinary capacity for acceleration. Yet, the feeling of security and safety which you will acquire after a few miles should not tempt you to become careless.

Therefore, adjust the speed of your car to the conditions of road, traffic and weather, and always be ready to bring your car to a stop when it is necessary. Be particularly careful when driving on wet or icy roads, for even a VOLKSWAGEN is apt to skid when not driven carefully under such conditions.

### **Rear View Mirrors**

can be adjusted to suit individual requirements.

Adjust the outer mirror so that you can look rearward alongside the car without having to turn your head or shoulders. You will then get a clear view of the road behind you.

The inner mirror of the Convertible is adjustable to insure a perfect view, no matter if the top is lowered or raised.

With the top in the raised position, turn the mirror holding rod down and push the mirror toward the windshield until the stop can be felt.

With the top lowered, pull the mirror back until the stop can be felt and turn up the holding rod.

### **Passing Other Cars**

Pass other vehicles with consideration. Always be sure that the road is clear ahead of you, and look out for cars approaching you from the opposite direction. A brief look in your rear view mirror will tell you whether another car is about to pass you from behind. And here is another warning: Never try to pass a car when approaching a curve, where vision is not clear, and never pass a vehicle at the crest of a hill, or at crossroads. You never can tell what lies ahead of you.

Be fair and do not step on the accelerator pedal when another car tries to pass you. You will endanger your life and others.

### **Stopping Your Car Temporarily**


**When stopped at an obstruction, a traffic light or railroad crossing, do not wait with the clutch pedal pressed down and the gear lever in position. Shift to first gear shortly before moving on again, it will preserve the clutch.**




## Parking your Car

in a space between two other cars that are parked at the curb can be easier if you heed the following advice:


Stop your car level with the car in front of the space. Turn the steering wheel sharply to the right and back your car slowly into the gap.



When the front bumper of your car is level with the rear bumper of the car ahead of you, turn the steering wheel fully to the left, and back up further toward the curb.



Now turn the steering wheel to the right again and pull up a little bit, until both ends of the car come as close to the curb as possible.



When parking on a steep slope, set the handbrake to stop the car rolling. As a precautionary measure, it is advisable to engage first or reverse gear in addition to the handbrake. And do not forget to take the key out of the ignition switch before you leave your car

Do not forget to shut the fuel tap when parking on a grade with the rear end of the car downwards.

Prior to locking the driver's door secure the door on the other side by pushing the inside door handle forward. The vent wing handle is locked by turning it until the push button is heard to spring out.

## COLD WEATHER HINTS


### In Winter

your VOLKSWAGEN has two features which you will most appreciate:

#### Air Cooling and Heating

You may expose your car to bitter cold without fear: – its air-cooled engine will always be ready to start. You will drive in warm comfort, well protected from the weather, while a current of warm air will keep your windshield free from condensation and frost. The increased stress that your car has to stand in winter because of frost and dampness can be easily coped with if you observe the recommendations presented in this section.

**Never attempt to influence the cooling and heating of your car in winter by covering the air intake slots below the rear window.** This would be harmful to the engine, as the inflow of fresh air for the carburetor and the heating would be seriously affected. The intake of cooling air is already efficiently controlled by the thermostat.



#### The Warm Air Heating

of your car can be regulated by a rotary knob situated adjacent to the gear lever:

- Anti-clockwise – On (1)
- Clockwise – Off (2)

Heating of your car will take place more quickly if you open a vent window so that the blower can force the warm air more easily into the otherwise well sealed interior.

#### Engine Oil

SAE 20/20 W oil will not congeal at temperatures above 0° C (+ 32° F) and will permit easy starting of the engine. If, however, temperatures below freezing point are anticipated the use of SAE 10 W is recommended.

This grade of oil may remain in the engine with safety when the temperature again rises to a higher range. Should it become necessary to add oil in the period between two regular oil changes, SAE 10 W oil may be used during lasting frost and SAE 20 oil when the average temperature rises. This means that the grades SAE 10 W and SAE 20/20 W can be mixed without detriment, but be sure to use always the same brand and type of engine oil.

The engine does not need to be warmed up before moving off, but it is advisable not to race the engine immediately after starting when the temperature is low.

### **Don't race the engine in severe frost to obtain a quick start.**

Only if your car is mainly operated over short distances **during cold weather** is it recommended to have the oil changed at more frequent intervals, say every 2,500 km. (1,500 miles), using the right HD oil. In the warmer seasons, oil changes extra to those laid down in the Lubrication Chart are unnecessary and uneconomical.

In territories where **exceptionally low temperatures** prevail (below  $-25^{\circ}\text{C}$  /  $-13^{\circ}\text{F}$ ), the use of SAE 5 W is recommended: this should be changed every 1,250 km. (750 miles). The oil strainer should be cleaned at the same time.

### **Transmission Oil**

SAE 90 gear oil is recommended for use when the average temperature will not be lower than  $0^{\circ}\text{C}$  ( $+32^{\circ}\text{F}$ ). However, where the temperature is expected to remain below freezing point for any length of time, SAE 80 grade should be used.

### **The Chassis**

is particularly exposed to moisture in winter. You are therefore strongly advised to adhere strictly to our instructions for lubrication. If, in addition, you spray the bottom of the car with a special chassis oil, as a protection against rusting, you will prolong the life of your car, and reduce ice formation on the chassis when the road is wet and the temperature low.



### **The Brakes**

of all automobiles are more or less exposed to splashing water which in winter is apt to freeze in the brake drums. Therefore, when parking your car, do not set the hand brake, but shift to first or to reverse gear.

### **Tires**

Worn tires are apt to cause trouble in winter. For safety's sake replace them in time. To meet the special requirements in winter, so-called M+S tires are available. These special-tread tires are designed to give a better grip in mud and snow. They are either used on the rear wheels only or on all four wheels. However, during the rest of the year you should use the normal tires.

### **Chains**

You will need chains only when the roads are covered with snow or ice. Without such chains, the rear wheels of your car are apt to spin, and applying the brakes may result in the car skidding. Have the chains adjusted to the wheels, if you wish to avoid loss of time and inconveniences later on.

When driving on long stretches that are free from snow, the chains should be removed to avoid unnecessary wear of both chains and tires.

### **The Battery**

is under greater strain in winter than in warmer seasons because of the increased consumption of current when starting the engine and using the lights at night. Besides this, it is a characteristic feature of any battery that its efficiency decreases at lower temperature. If the car is mostly used over short distances, the battery may require additional recharging.

Therefore, have your battery checked regularly, and you will never encounter any starting difficulties.

### **Spark Plugs**

The normal spark plug gap is 0.7 mm. (.028").

In extremely cold weather reduction of their gaps to 0.4-0.5 mm. (0.16"- .020") will aid cold starting considerably.

# LUBRICATION

## **Proper Lubrication is of Vital Importance to Your Volkswagen**

The extra time spent in following these recommendations will be amply rewarded in the long run by your car's efficient performance. It is up to you to maintain the standard of safety offered by your VOLKSWAGEN, and to insure the long life and good service which you have the right to expect from this truly economical car.



### **To lubricate correctly means to lubricate amply and at prescribed intervals.**



Therefore, do not shy at the work connected with the regular lubrication service. A Lubrication Chart can be found on page 83, indicating the correct mileages at which to lubricate.

The Service Booklet makes it possible for you to have your VOLKSWAGEN lubricated at our authorized workshops by skilled hands, with the best available lubricants, at lowest cost and in a minimum of time. You really cannot afford to miss this opportunity.

### **Engine Oil Change**

Regular oil changes are necessary even if the very best branded oils are used. Dirty oil in your engines simply means increased wear and a shorter life for your engine. On the other hand, provided that HD oil is used, it is unnecessary and uneconomical to change the oil more frequently than called for in the Lubrication Chart.

The oil is drained by removing the plug in the oil strainer bottom plate. To insure complete drainage, it is important that the operation be performed while the engine is warm.




The engine is refilled with **2½ liters of HD oil** (for Service MS)  
(5.3 U.S. pints, 4.4 Imp. pints)

Flushing of the engine is unnecessary.

### The Oil Strainer

retains foreign matter and should be taken out and cleaned at every oil change. The two gaskets should be replaced each time the strainer is removed.

- |                  |                         |
|------------------|-------------------------|
| 1 - Gasket       | 5 - Gasket              |
| 2 - Oil strainer | 6 - Drain plug          |
| 3 - Gasket       | 7 - Nut and lock washer |
| 4 - Bottom plate |                         |



## Types of Lubricant and Recommended Usage

The advantages of using a

### **branded HD engine oil (For Service MS).**

HD oil is an oil having proved oxidation stability, bearing corrosion preventive properties and detergent-dispersant characteristics which tend to hold in suspension foreign contaminants which would normally deposit on engine parts. These foreign contaminants will drain out with the oil at the periodical oil changes. The detergent properties of HD oil will make the fresh oil darker after a short time of operation. This is quite natural and there is no reason whatsoever to change the oil earlier than called for in the Lubricant Chart.

### **Some more Information on Engine Oils**

It is left to your discretion to select an oil from well-known and dependable brands of the proper viscosity to suit your seasonal and driving requirements. In cases of doubt, refer to your authorized VW Dealer who will be glad to help you with your lubrication problems. It is recommended that you select "your" oil after the first 500 km. (300 miles) and stick to it at all future service oil changes. Viscosity of the lubricant is an indication of its resistance to flow at a given temperature. The SAE numbers classify lubricants in terms of viscosity, but with no reference to other characteristics or properties.

**SAE 30** engine oil is satisfactory in tropical climates where the temperature will frequently rise above 30° C (86° F).

**SAE 20/20 W** engine oil is recommended for use within the mild temperature range from +30° C to 0° C (+86° F to +32° F). It may also be used with safety, in temperatures temporarily outside these limits.

**SAE 10 W** engine oil is recommended for use if the temperature is anticipated to fall below 0° C (+32° F). It may also be used with safety, should temperatures rise above freezing point. A change of oil is, therefore, not necessary until the next regular mileage interval.

**SAE 5 W** This extremely light engine oil is for use in arctic climates below -25° C (-13° F) only.

For further details see page 32.

In some countries API Classification is applied (API = American Petroleum Institute). According to this classification, the HD oils suitable for the VW engine are referred to as "For Service MS".

Multigrade oils can also be used for the VW engine.

**Additives** should not be mixed with HD oil.


### Ignition Distributor

The amount of grease at the breaker arm fiber block should be checked and, if necessary, replenished at the specified intervals.

Every 5,000 km. (3,000 miles), apply 1 drop of oil to the felt ring in the contact breaker base plate.

### Transmission and Differential

The transmission gears and the differential of your VOLKSWAGEN are combined in the transmission case and are both lubricated with a normal gear oil. If this type of oil is not available, hypoid oil can be used in exceptional cases. An early change of oil, while the gears are being broken in, will contribute to a smoother operation of the transmission. The used oil should be drained by removing both of the drain plugs, with a 17 mm. box wrench while the oil is still warm.



Then refill with **2.5 liters (5.3 U.S. pints, 4.4 Imp. pints)** of gear oil.

The synchromesh transmission oil drain plugs are magnetic and should be carefully cleaned at 500 km. (300 miles), 2,500 km. (1,500 miles), 5,000 km (3,000 miles) and then at every oil change.



At 2,500 km. (1,500 miles) and 5,000 km. (3,000 miles) do not drain the oil when a mere cleaning of the oil drain plugs will do, removing them one at a time and closing the drain hole temporarily with a spare plug or a wooden plug. Then check the oil level. Keep the lubricant level somewhat below the edge of the filler hole.



In order to maintain the characteristics of the gear oil, it should not be mixed with any other oil, as the two will not blend.

### Lubrication Additives

No additives of any kind should be mixed with the transmission oil.

### Steering Gear

The steering assembly should be lubricated exclusively with SAE 90 gear oil and under no circumstances with grease or other oils. It is accessible through an opening underneath the spare wheel. The level of the oil in the steering case should be kept somewhat below the filler plug hole.



### Chassis


Proper lubrication of the front axle bearing points is best done by raising the front axle so that the weight is taken off the wheels. Prior to lubrication, the grease fitting should be cleaned thoroughly with

a clean piece of cloth, so as to avoid any dirt or foreign matter entering the fittings. The tip of the grease gun should be pressed on to the fitting, and then grease should be injected until the excess grease begins to emerge at the edges of the lubrication point.

Not even the smallest quantity of grease should come into contact with the tires and brake hoses. If it does these parts must be cleaned thoroughly.

**If the car is driven mainly over rough roads, we recommend you to lubricate torsion arm links and outer tie rod ends at more frequent intervals, say every 1,250 km. (750 miles).**

Annually, at the beginning of the cold season, the cables of clutch, accelerator and heating and the clutch cable adjusting nut should be cleaned and greased.



### **Brake Cables**

Inject some grease at the prescribed intervals into the fittings of the conduits in order to maintain easy operation of the brake cables.

### **The Front Wheel Bearings**


are provided with sufficient grease at the factory. The caps on the front wheel hubs must be free from grease.

According to the maintenance chart the front wheel bearings should be cleaned and repacked with the grease specified under the heading "Lubricants" every 50,000 km. (30,000 miles). The brake drums must be removed

for this purpose. Finally the front wheel bearings must be adjusted. In order to avoid damage to the bearings this operation should, if possible, be carried out in a VW Workshop.

## Doors

The door lock striker plates should be very lightly greased. Apply a few drops of oil to the hood hinges. The door hinges should be oiled at every lubrication service or, better, once a week after dust and dirt have been removed.



Door cylinder locks should be treated with graphite only. Blow a small quantity of powdered graphite through the key hole. Dip the key into the graphite, insert key and move it back and forth several times.

To oil the door lock, apply a few drops of oil to the hole situated above it.

## Window Regulators

Access to the window regulator is obtained by removal of the regulator handle, inside door handle and trim panel. To take off a handle press down the escutcheon plate and push out the pin. The trim panel is held by snap fasteners. Gear and joints of the window regulators (on the



Convertible, the rear quarter window winder, too) should be greased, if found necessary after a long period of service.

### **Front Seats**

The upper and lower sliding surfaces of the seat runners should be greased. Only a small amount of grease will provide easy movement of the seats. Prior to lubrication, wipe over the runners with a rag. To remove the seat, slide it fully towards the front. When installing the seat, hook the spring in position.




## Gear Lever

Should the gear lever require lubrication, this can be done with the lever removed. Remove the front floor covering and the two screws that attach the lever dome to the frame tunnel and lift off lever, dome and spring as a unit.

The contact surfaces in lever dome, at stop plate and lever ball socket should be amply provided with universal grease. When installing stop plate, make sure that the turned-up edge is on the right-hand side.

After installation, make sure the gears engage properly. If necessary, correct position of gear lever.



## Convertible Top

Whenever necessary, the joints of the top linkages are lubricated by applying a few drops of oil after dust and dirt are removed. Care should be taken to avoid oil getting on to the top cover, as oil has a detrimental effect on the rubber seal.



## WHEELS AND TIRES

Under-inflation or over-inflation are the most common causes for tire failures. High speed driving and cornering, skidding to a stop and striking curbs or objects on the road wears tires more than many miles of careful driving.

Avoid overloading the car and protect the tires from intense sunlight, fuel, or oil.



Normal wear may be kept at a minimum by interchanging wheels and tires including the spare at approximately 5,000 km. (3,000 miles) intervals. Interchange wheels as shown in the illustration. This is a very good time to check the tires for foreign matter and outer damage. The tire tread should never be allowed to wear down to a thickness of less than 1 mm. (.03") which is the absolute minimum required for safe usage. A drop of oil applied to the wheel mounting bolts facilitates the next wheel change.


For smooth running at high speeds and long tire life, it is important to have the wheels balanced statically and dynamically when tires have been repaired. As after longer running periods the wheels can be out of balance owing to natural wear of the tires, they should be balanced statically and dynamically every 10,000 km. (6,000 miles).

When the tires are being mounted, the red mark on the sidewall should be lined up with the valve to insure better balancing of wheel and tire.

### Changing wheels


Changing a tire on the road in the rain is certainly not pleasant. However, it will be easier after you have read these few lines which tell you the correct way. Underneath the front hood, you will find the spare wheel, jack and tool kit.

- 1 - Set the hand brake securely and block the wheel opposite the one being removed to prevent the car shifting off the jack.
- 2 - Insert the jack into the square tube below the body sill panel in front of the rear fender and push down the jack base plate until it makes contact with the ground.
- 3 - Remove hub cap by means of the hub cap removal tool.
- 4 - Loosen wheel bolts by means of the socket wrench before wheel is fully jacked up.



- 5 - Raise jack until tire clears ground.
- 6 - Remove wheel bolts and take off the wheel.

- 7 – To install the spare wheel, operate the jack until the five holes in the wheel are nearly lined up with the holes in the brake drum.
- 8 – First, insert one wheel bolt only. Tighten it to such a degree as to allow the wheel to be swung around this point by hand until the remaining holes in the wheel and brake drum coincide.
- 9 – Insert the remaining bolts until the countersunk heads are centered in the corresponding recesses of the disc-wheel.
- 10 – Tighten all bolts diametrically opposite in turn.
- 11 – Insert one end of the jack operating rod into the hole marked "ab" and apply a light pressure on the opposite end of the rod to lower the car to the ground. Keep on exerting a pressure on the operating rod to allow the base plate to be pushed up, and remove the jack.



- 12 – Make sure that all bolts are tight.
- 13 – Install hub cap firmly and make sure that it is tightly seated.



## CARE OF THE CAR



### Clean and Smart Appearance

To keep the VOLKSWAGEN looking smart and new should be a matter of pride to the driver or owner of the car. It is our object to provide you with paintwork which not only looks good and has a sparkling lustre but is most durable. A chemical treatment protects the body against rust and corrosion and anchors the paint securely to the metal. The finish is of high-quality synthetic resin (enamel) and carefully blended to obtain the most beautiful shades.

You will realize the importance of the paint finish if you consider that it is exposed to the elements; it has to resist sunshine, rain, dust and dirt. That is why periodic care of the body is necessary to retard any disintegrating process.

### Washing Your Car

Wash your new car frequently during the first weeks as this is good for the finish. When washing you require a soft sponge for the body, a soft brush for the wheels, a sturdy, long-handled brush for the chassis, and plenty of clean water. For drying the car you need a chamois.

The chassis and lower part of the body should first be flushed with water, to soak off the dirt, and afterwards a brush should be used.

Spray the exterior finish of body and wheels evenly with water until dirt is soaked off. Do not allow a powerful jet of water to hit the painted surface. Using plenty of clear water, remove dirt with a sponge. Care should be taken to clean the sponge at short intervals to avoid scratching the polished parts.

There are some approved auto soaps and detergents which greatly facilitate this job. Avoid the use of any product which has not been recommended by your VW Dealer. It is of utmost importance to rinse the body thoroughly with water after the car-wash has been applied to insure that no traces of it remain on the body.

After washing, rub down with a clean chamois to prevent water spots.

### **Preservation (Waxing)**

means to restore to the finish certain substances it has lost by exposure to the weather. As these substances are vitally important to the elasticity of the finish, it is necessary to apply a protective water-repellent coat of wax to the body. The intensive cleaning effect of the shampoo removes this protective coating so that it should be renewed accordingly. A preservative specially produced for the finish of your VOLKSWAGEN can be obtained under the designation "L 190" from your VW Dealer. The body should be waxed after the first eight or ten weeks and then regularly at intervals of from six to eight weeks - in any case after each soap or detergent washing, as already mentioned. Applying the preservative is quite easy: With a soft cloth, spread a thin film on the finish, then rub it down when dry (after about 20 minutes), using polishing cotton or a soft polishing cloth, until iridescent colors can no longer be seen when you are standing at an angle to the polished area.

Of course, the car must be washed and dried carefully prior to applying the preservative.

### **Polishing**

You should polish your car only if its appearance has been strongly affected by road dust, sunlight and rain as a consequence of insufficient care, or if the application of the preservative no longer restores the original lustre. Avoid the use of abrasives or chemically harmful products, even if their first application seems to give satisfactory results. A special

polish for treating the synthetic-resin (enamel) finish is also obtainable from your VOLKSWAGEN Dealer under the designation "L 170".

Prior to applying the polish, the car must be washed and dried carefully. Dust or dirt should never be wiped off dry. The polish should be applied with a soft clean cloth or polishing cotton – use a straight horizontal or vertical motion rather than a circular motion. After some time of rubbing you will feel a slight resistance, which indicates that the ingredients of the polish have settled in the finish and that the solvent has evaporated. Now take clean polishing cotton and rub the body down until the high polish is restored. Do not apply the polish on too large an area of the body at a time.

A subsequent application of the preservative and your efforts will be rewarded with a long-lasting shine.

**Never wash, wax or polish the car in sunlight or when the metal is warm.**

### **How to Remove Spots**

Water alone will not always remove splashes of tar, oil traces, "baked on" insects, etc. On principle, such foreign matter should be removed as soon as possible, for if you neglect this, permanent damage may result to the finish.

### **Tar Spots**

An unpleasant sight, to be noticed particularly on light-colored cars, are tiny tar spots which show up on the fenders on hot days when driving on newly tarred roads. Tar splashes have a tendency to corrode the finish within a short time and should be removed as soon as possible. On the road, you usually have nothing at your disposal but fuel, which may be applied with a soft cloth. Kerosene or turpentine oil may also be used. After this, the treated spots should be washed with a mild, lukewarm soap-solution, and rinsed, in order to remove traces of the cleansing agent. It is, however, better to use our preservative already mentioned, which renders the treatment with soap-solution unnecessary.

## **Insects**

are caught especially during the night, in hot weather, by fenders, head-lights, and front hood. Once baked on they are very difficult to remove with water and sponge, and should be treated with lukewarm soap-solution.

## **Trees in Bloom**

especially lime-trees, in many instances drop tiny quantities of liquids. Cars that have been parked underneath such trees become "freckled" all over. These stains, too, can be readily removed with soap-solution.

After-treatment of the cleaned spots with the preservative is strongly recommended.

## **Cleaning Sun Roof**

It should be cleaned with a weak, lukewarm solution of a pure soap (soap flakes) and then washed down thoroughly with clean water. Spots should never be removed with aromatics such as paint thinners or spot removers containing chlorine as these will attack the plastic. Stains should be removed with a cloth damped with benzine followed by a wash with soapy water and a final rinse with clean water.

Be sure the cover is thoroughly dry before opening the sun roof.

## **Care of the Convertible Top**

The appearance and life of the top greatly depend on a proper care and maintenance.

The top must always be perfectly dry before lowering it. After driving on dusty roads, lightly beat out the top and brush the fabric in line with the pile as any sharp foreign particles will harm the top fabric if not removed quickly.

Damage due to friction may occur should the lowered top not be tightly held in position by the catches which engage in the slots cut in the side rails. In such cases, the catches should be screwed further into their retainers. To do this, the lock nuts are loosened before and tightened after the adjustment.

Never use fuel or other volatile cleaners to remove spots, as they destroy the rubber ply in the top cover, result in leaks and shorten the life of the top.

The top should be washed only when it is exceptionally dirty, and not more than twice a year. Only use clean water free from chemicals or other additives. Prior to washing, beat out the top and then brush. Use lukewarm water and a mild soap, only such soap as castile or olive oil base soaps should be used. Moisten the top with clean water and apply the thick suds. Scrub the top with a soft brush. After scrubbing, flush off the suds with clean water. If necessary, again scrub with suds. There should be no trace of the suds when the top has been flushed. Be sure the top is thoroughly dry before lowering.

After washing the top, clean the finish of the car by flushing with clear water and rubbing dry with a clean, soft cloth.

### **Chromium-Plated Parts**

should be lightly coated with a chromium wax, chromlin for instance. The use of grease is not recommended as this will collect dust and dirt.

### **Care of the Cloth Upholstery**

If no vacuum cleaner is available, the upholstery should be cleaned thoroughly with a brush or whisk broom. Grease and oil stains on the upholstery or interior trim cloth are removed with cleaning fluid. To avoid forming a ring do not pour the cleaning fluid directly on the spot. Moisten a clean, uncolored cloth with the fluid and rub with a circular motion, starting outside the spot and working inwards to the center.

Other stains can generally be removed with lukewarm soap-suds.

### **Care of Leatherette Upholstery**

Cleaning of leatherette upholstery with a soft cloth or soft brush is recommended. Special care should also be taken to remove dust and dirt from the seams. Better results can be obtained using a soft whisk broom and suds of any mild soap (castile or olive oil base) in lukewarm water (rain, boiled or soft water). Use the water sparingly, as otherwise the upholstery requires a long time to dry, if water trickles through the seam stitches. Grease and paint spots should be wiped off before they dry up. Soaked-in spots can be removed by carefully using a rag moistened with gasoline or alcohol. Spots caused by shoe polish can be removed by means of turpentine. Use these agents carefully and sparingly as, otherwise, they

would tend to dissolve the dust-repellent finish of the leatherette. Solvents such as trichlorethylene or paint thinner must not be used for cleaning. After completing the cleaning operation, use a clean, soft cloth to polish the surface of the leather. Treat the upholstery seams carefully. Never use furniture polishes, oils, varnishes or cleaners on leatherette upholsteries. They will injure the finish.

### **Care of Leather Upholstery**

The leather upholstery should be serviced in accordance with the instructions given for the leatherette upholstery. After the upholstery has been wiped dry, a suitable cleaner may be used to clean, preserve and brighten the appearance.

### **Cleaning Glass**

Windows can be cleaned by washing with water and wiping dry with a clean, soft linen cloth or chamois. To facilitate this task on the windshield, the arms of the windshield wipers may be tilted forward. To clean exceptionally dirty windows, use alcohol or household ammonia and lukewarm water.

### **Door and Window Weather Strips**

It is important to keep the rubber parts undamaged and supple to ensure perfect sealing of doors and windows on the Convertible. A light coating of powdered talc on all rubber parts every time after the car is washed is recommended to retain the original flexibility and to reduce friction. Noises due to friction between the side windows frames and the rubber strips can easily be eliminated on the Convertible by using a mixture of glycerine and talc.

### **Airing the Interior**

If the car is left stationary for a long period in your garage, regular airing should be carried out. Permit air to circulate freely through the body by opening the doors and lowering the windows to prevent the formation of mould and dampstains.

# MAINTENANCE



The VOLKSWAGEN SERVICE ORGANIZATION has made available for you an extensive network of Authorized VW Workshops staffed with well trained and experienced men, and equipped with all the special tools and appliances required to service your car. If ever you should need service when touring and away from home, look for the well-known VW Service Sign. The workshop displaying this sign is your assurance of the same expert, prompt, and courteous service you are accustomed to receive at home.


In case you can't get to an Authorized VW Workshop in time, we are giving you some information which, if needed, will help you to carry out normal maintenance work. However it is important that repair jobs which are beyond your capacity should be performed by the nearest VW Workshop. There your car will be given expert treatment by those familiar with its construction.

This will save you time, inconvenience, and money.

## Servicing Air Cleaner

The air cleaner filters particles of dirt and grit from the air used for combustion. Regular servicing is especially important in dusty areas. A dirty air cleaner decreases operating efficiency and increases fuel consumption. It should, therefore, be cleaned every 5,000 km. (3,000 miles).

To service air cleaner, remove it from the engine and take off the cover that houses the filter element after having detached the clamps. Remove dirty oil from reservoir and refill to level indicated with approx. 0.25 liter (0.53 U.S. pt.; 0.44 Imp. pt.) SAE 20 engine oil. Rinse the filter element with kerosene or any other degreasing fluid and allow the fluid to drain from the filter.




1 - Filter element, 2 - Gasket, 3 - Oil reservoir

If the car is being used under desert conditions or in places where the air is laden with dust, it is up to you to prevent premature wear by servicing the air cleaner more frequently than specified above.

Air cleaner service is overdue if there is no thin oil above the sludge and dirt which has accumulated in the fluid reservoir.

### Adjusting and Replacing the Fan Belt

To adjust and replace the fan belt, remove nut and outer half of generator pulley. When loosening or tightening nut, insert a screwdriver in the slot



cut into the inner half of the pulley, and support it against upper generator housing bolt. The adjustment of the fan belt tension is effected by means of spacer washers situated between the two pulley halves. Belt slackness is taken up by removing one or more washers. If the belt has too much tension, one or more washers should be added.

The fan belt should not be too slack, nor should it be too tight. Newly installed belts will stretch to some extent and should, therefore, be checked and adjusted after 500 kilometers (300 miles) running. A further adjustment is not necessary as the tension will not alter any more.



## Check Automatic Air Intake Control



Incorrect adjustment of the throttle ring is responsible for the engine attaining its operating temperature either too quickly or too slowly. If the throttle ring opens too far, it may foul the fan resulting in considerable noise.

The automatic air intake control is correctly adjusted if

- 1 - the throttle ring rests slightly preloaded against the air intake flange when the engine is cold.
- 2 - with the engine warm, the distance from the top edge of the air intake flange to the edge of the throttle ring measures 25-30 mm. (1-1.2 in.)  
(a) when the upper end of the thermostat in the right lower heater channel touches the stop of the support.

## Check Adjustment

- 1 - Warm up the engine until the upper end of the thermostat touches the stop of the support.
- 2 - Unhook throttle ring return spring.
- 3 - Loosen throttle ring operating lever.
- 4 - Adjust throttle ring so that it opens 25 mm. (1 in.).
- 5 - Tighten operating lever and insert return spring.
- 6 - Check thermostat-controlled cooling air intake for proper functioning.



## Cleaning the fuel filter

The fuel pump filter prevents foreign matter and dirt from entering the carburetor.

The filter should be cleaned at the prescribed intervals.


- 1 - Remove retaining screw by means of a 18 mm. socket wrench and take off cover.
- 2 - Take out filter and wash out in benzine.
- 3 - Dry filter thoroughly and install it. The reinforcement ribs should be at the top.
- 4 - Install cover, and tighten screw making sure that the gasket is not omitted.

### Carburetor Adjustment

The carburetor is tested at the factory and properly adjusted to the engine. Do not alter this adjustment by exchanging the jets for other than the prescribed sizes. This would be detrimental under normal operating conditions and may result in hard starting, excessive fuel consumption or unsatisfactory engine performance. Only the idling of the engine may call for an occasional readjustment.

**Before attempting to adjust the carburetor, make sure the engine is at normal operating temperature.**

Check that the idling adjusting screw is no longer resting on the fast idle cam of the automatic choke.



- 1 - Turn the idling adjusting screw (1) in or out until an idling speed of about 550 r.p.m. has been attained.
- 2 - Turn the volume control screw (2) clockwise until the engine speed begins to drop, then give it a  $\frac{1}{4}$  to  $\frac{1}{3}$  turn in anticlockwise direction.
- 3 - Re-adjust the idling adjusting screw.

The adjustment is correct if the engine does not stall when the throttle is either suddenly opened or shut with the clutch pedal depressed. Poor idling may also be the result of damaged gaskets, intake manifold flanges not sufficiently tightened, faulty ignition or leaky valves. Skill and experience are required to check and adjust the carburetor, automatic choke and the accelerator pump. For this reason you should leave this job to an Authorized VW Workshop.

### **Adjustment of valve clearance**

The following procedure should be carried out only in emergency when it is impossible for you to reach a VW Workshop.


Remove cylinder head cover.

Valve clearance should be 0.20 mm. (0.008") for the intake and exhaust valves with the engine cold.

**Adjust valve clearance only when the engine is cold.**

The arrangement of the cylinders can be seen by the numbers 1 to 4 indented in the cover plates.

Valve adjustment may be made in the following sequence: No. 1 - No. 2 - No. 3 - No. 4 cylinder.





Adjust the valves when the piston of the corresponding cylinder is in top dead center position of the compression stroke. Starting with the No. 1 cylinder, crank the engine over slowly to the left by the fan pulley, until both valves are in fully closed position and the timing mark on the pulley is in line with the vertical jointing faces of the crankcase.

If the clearance requires adjustment, loosen the lock nut of the adjusting screw and turn the adjusting screw as required to obtain the proper clearance. Tighten the lock nut and recheck the clearance. Readjust if necessary. Check and adjust the other valves to the proper clearance in this manner by turning the crankshaft anticlockwise another 180° for each cylinder.

### Checking the Spark Plugs

The spark plugs must be thoroughly maintained for easy starting and economical operation. Remove the plugs and inspect their exterior.



$a = 0.7 \text{ mm. (.028")}$

#### Electrodes and insulator

- medium grey – good adjustment of carburetor and correct performance of spark plug,
- black – mixture too rich,
- light grey – mixture too lean,
- oiled up – failure of spark plug or piston ring blow-by.

Clean the spark plugs with a brush and a chip of wood and blow them out. Inspect the spark plug for cracked insulator and burned or pitted electrodes. The insulator should be clean and dry on the outside in order to avoid short circuits.

Check the electrode gap (0.7 mm. = .028") and reset if necessary by bending the outer electrode. Use a proper gasket when installing the plug. Generally speaking, you may count on a spark plug service life of up to 15,000 km. (9,000 miles).

## Check Compression

After warming up the engine remove all 4 spark plugs. Operate the starter motor with the accelerator pedal fully depressed and the throttle in a wide-open position. The compression is checked by insertion of an accurate compression gage into the spark plug hole of each cylinder.

Result: good	7.0-9.0 kg./sq. cm. (100-128 lbs./sq. in.)
sufficient	4.5-7.0 kg./sq. cm. (65-100 lbs./sq. in.)
insufficient	below 4.5 kg./sq. cm. (65 lbs./sq. in.)




## Ignition and Timing

Particular attention should be paid to correct ignition timing. The operation of the engine will be seriously affected if the ignition breaker points are not properly timed and correctly spaced. In many cases poor performance, high fuel consumption and even severe damage to the engine can be the result of incorrect ignition setting. The ignition must not be advanced arbitrarily, not even when using premium grade fuels.

Adjustment may only be carried out **with the engine cold.**

## Adjusting Contact Points

Remove distributor cap and rotor. The breaker contact points are adjusted by cranking the engine until the fiber block on the contact arm rests on the highest point of the cam lobe. Then loosen the stationary point locking screw, and insert a screwdriver between the two small lugs on the contact plate and the slot in the fixed point arm. Turn the screwdriver to adjust the gap to the correct clearance of 0.4 mm. (0.016").




Tighten lock screw and recheck the gap. If the points are burned, rough or pitted, clean them with a contact file or, better still replace them. The distributor cap should be clean and dry to avoid short circuits. Replace rotor.

**After the contact points have been adjusted, it is absolutely necessary to check the ignition timing with the engine cold.**

### Ignition Timing

Crank the engine clockwise until the right-hand mark of the crankshaft pulley lines up with the vertical crankcase jointing faces and the distributor rotor arm is in the position for firing on No. 1 cylinder (see mark on rim of distributor base). Loosen the clamp screw below the distributor base and rotate the distributor body clockwise until the contact points are closed.




Now switch on the ignition and rotate the distributor slowly anti-clockwise until the contact points just start to open. This may be seen and heard, for a spark will jump from one point to the other.

To obtain a more accurate adjustment for maximum results, it is advisable to use a test lamp or an ignition timing light. The test lamp should be connected to the coil primary lead terminal and to earth. The lamp will light up as long as the contact points are kept open by one of the four cam lobes of the distributor shaft. After the adjustment is completed, tighten the lock screw and replace the cap on the distributor. Check the ignition timing again.

### Battery Maintenance

Ready starting of the engine depends upon perfect condition of the battery. The battery should, therefore, be checked and maintained regularly.

The battery cover can be easily removed by raising the rear seat, removing the kick board and opening the battery snap fastener. The state of charge of the battery may be checked by means of a battery hydrometer. The



specific gravity of the battery liquid will increase with the charging of the battery. Tested with the hydrometer, the gravity can be read from the scale of a float.


Battery fully charged	1.285 = 32° Bé
Battery semi-charged	1.230 = 27° Bé
Battery fully discharged	1.142 = 18° Bé

In addition, a voltmeter test should be made to insure that the battery is in good operating condition and able to provide the necessary current. The voltage of each cell should not fall below 1.6 volts while the reading is being taken (10–15 seconds). Otherwise the cell is discharged or defective. Under no-load conditions each charged cell should read 2.0 volts.

Add distilled water to each cell to bring the level above the plates. The acid level has to be adjusted in accordance with the acid level mark. Losses by evaporation may only be replenished by adding distilled water. Never add acid, unless it is known that acid has been spilled from the battery. Check specific gravity afterwards and compensate if necessary.

Check condition of the battery posts and the cable terminals. They must be clean and tight to prevent excessive electrical resistance. Use a stiff brush to remove corrosion from both posts and terminals. Coat the clean posts and terminals with light grease to prevent corrosion. Make sure that the battery is properly grounded.

When laying your vehicle up for a prolonged period, it is advisable to take the battery to a workshop for storage. A battery which is not in constant use will discharge itself in time and this can result in permanent damage to the plates if the battery is not checked about every 4 weeks and charged as necessary.



Dimensions:  $a = 1004 \text{ mm (39.5")}$


$b =$  the height of the headlamp center from the floor

$c = 50 \text{ mm (2")}$  at a distance of 5 meters (16 ft. 5") from the aiming screen

### Aiming the Headlights

If no headlight aiming device is available, proceed as follows:

- 1 - Position the vehicle on level ground 5 m. (16 ft. 5 in.) in front of a dark wall which will serve as a screen. The tire pressures must be correct.
- 2 - Next draw two crosses on the wall as shown in the sketch.
- 3 - The longitudinal center line of the vehicle must be aligned exactly between the two crosses on the screen.
- 4 - The rear seat must be loaded with one person or a weight of 70 kg. (154 lbs).
- 5 - The headlamps should be adjusted horizontally and vertically with the beams dimmed.
- 6 - Each lamp must be adjusted separately with the second lamp covered up.
- 7 - Adjust the headlamp by turning the slotted screws in the headlamp rim.






### Vertical Adjustment

The headlamps should be aimed vertically so that the light-dark border line is horizontally on the adjusting line to the left of the cross and slopes upward to the right of the cross.

### Horizontal Adjustment

The headlamps should be aimed horizontally so that the angle on light-dark border line is exactly on the center of the cross.



### Headlight Bulb Replacement

Loosen the slotted fixing screw at the bottom of the headlight rim. Pull out the lens and reflector unit. Turn the cap to the left and take the holder out of the reflector. Pull the connector off the bulb base and replace the bulb.

When installing the lamp unit check that:

- 1 - The lug in the lamp holder engages in the notch provided in the reflector.
- 2 - The contact strip is located on the base of the parking light bulb.


Never touch the bulb with the bare hand, but only with a clean cloth or a paper serviette, etc.



### **License Plate Light Bulb Replacement**


The license plate light is accessible after the rear hood has been partly lifted up. To replace the bulb, loosen the two fixing screws and pull out the lens.

Replace the bulb.



### **Front Flashing Indicator Bulb Replacement**

Remove the Phillips screw, take out the housing and lens, and replace the bulb.



### **Stop/Tail/Flashing Indicator Bulb Replacement**

To replace the bulbs of the two combined stop and tail lights on the fenders, remove the slotted screw, lift the case away from the body, and pull out the bulb holder. When inserting the bulb holder, make sure the tongue at the bulb holder disc engages properly in the slot provided in the reflector.

## Warning and Instrument Light Bulb Replacement

The warning lights for oil pressure, charging, flashing indicator and headlight high beam as well as the speedometer lights are accessible by lifting the front hood and removing the cover in front of the instrument panel. The bulb sockets can easily be pulled out from their holders.

1 - Speedometer lighting bulb


Warning lamps:

2 - Headlights

3 - Oil pressure

4 - Flashing indicators

5 - Generator




## Replacing Fuses

The fuse box, with transparent cover, is located under the instrument panel near the steering column.

When a fuse has blown, it is not sufficient merely to replace it by a new one. Inspect the electrical system for evidence of short circuits or other faults which may have caused the fuse to blow.

Under no circumstances use fuses which have been patched up by means of tin foil or wire as they would be liable to cause severe damage. We suggest that you always carry a few spare 8 amperes fuses.



**Fuse box under the instrument panel**

## Checking Brakes

Excessive travel of the brake pedal before braking is effected indicates too much clearance between brake shoes and drum. You can check the brake linings by looking through the inspection hole in the brake drum. Inspect them every 5,000 km. (3,000 miles). They should be not less than 2.5 mm. (.1") thick. If they are badly worn, replace them.

## Hydraulic Brakes

Brake adjustment should be carried out in an Authorized VW Workshop. However, if an emergency arises where the brakes must be adjusted before you can reach the next repair shop, the following procedure is recommended.

The transparent fluid reservoir is located under the front hood behind the spare wheel. Use only **Genuine VW Brake Fluid** or **Lockheed Brake Fluid**. The fluid reservoir should be kept at least  $\frac{3}{4}$  full at all times. Handle the brake fluid carefully. It may damage the paintwork severely.




## Bleeding Hydraulic System

Spongy or excessive brake pedal travel indicates the presence of air in the system.

- 1 - Remove rubber cap of the bleeder valve of one wheel cylinder and attach one end of the brake bleeder hose to the valve.

- 2 – Place the opposite end of the bleeder hose in a glass container partly filled with brake fluid so that the end of the hose is submerged.
- 3 – Turn the bleeder valve to the open position (1–2 turns), using a 7 mm. wrench.
- 4 – Pump the brake pedal several times, forcing fluid through the lines until bubbles cease to appear in the container. Make sure that enough brake fluid remains in the fluid reservoir, since otherwise air will be sucked in.
- 5 – The brake pedal should be kept in the fully depressed condition until the bleeder valve is closed.
- 6 – Remove the bleeder hose and replace rubber cap.
- 7 – Repeat the above operations on the other wheels.  
When the bleeding is completed, top-up the master cylinder reservoir with brake fluid if necessary.



front



rear

### Adjusting Hydraulic Brake

Too much free travel of the brake pedal is an indication that the clearance between brake shoes and brake drums has become too great and that the brakes need adjustment or relining.

- 1 – Remove hub caps.
- 2 – Jack up a wheel and turn it until the hole in the brake drum is in line with one of the adjusting nuts.


- 3 - Insert a screwdriver through the hole and turn the adjusting nut in the direction indicated by the arrow, using the screwdriver as a lever, until a slight drag is noted when wheel is turned by hand.
- 4 - Repeat procedure on the other adjusting nut. Note that the two nuts turn in opposite directions.
- 5 - Back off the adjusting nuts by 3 to 4 teeth until the wheel can be turned freely.
- 6 - Repeat the above operations on the other wheels.
- 7 - Install hub caps and make sure they are tightly seated.

Before and after brake adjustment it is advisable to depress the brake pedal sharply so that the brake shoes come into the proper position in the drum.

When adjusting the rear brakes, the hand brake must be released.

### **Adjusting Hand Brake**

- 1 - Jack up both rear wheels.
- 2 - Fold back hand brake lever rubber boot.
- 3 - Tighten adjusting nuts on the front ends of the brake cables to a degree which will still allow the rear wheels to turn freely when the hand brake is released.
- 4 - Pull up hand brake lever by two notches and make sure both rear wheels have the same braking effect. At the fourth notch it should be impossible to turn the wheels by hand. Lock the adjusting nuts.




### **Clutch Pedal Free-Play**

Easy gear shifting and complete transmission of engine performance to gears and wheels can only be guaranteed if the clutch is adjusted as specified.

Measured at the clutch pedal, this free-play should amount to 10-20 mm. (0.4-0.8 in.) (a). The clearance may be adjusted at the adjusting nut on the cable end.

- 1 - Release lock nut on the threaded cable end.
- 2 - Adjust clutch clearance by turning the adjusting nut. Depress clutch pedal several times and recheck pedal free-play.
- 3 - When the correct adjustment has been reached, hold adjusting nut in position and tighten lock nut.
- 4 - Grease clutch cable adjusting nut with Universal Grease.



### Steering Gear

The need for adjustment will be evidenced by the development of excess free-play in the steering wheel. The play should be as small as possible, but care must be taken to allow the front wheels to resume their straight-ahead position, after the car has taken a turn. The adjustment should be carried out only in an Authorized VW Workshop. If, however, a workshop is out of reach, proceed as follows:

- 1 - Turn the front wheels to the straight-ahead position.
- 2 - Loosen lock nut and sector shaft adjusting screw on top of the steering gear case.
- 3 - Adjust worm shaft end play: Loosen adjusting sleeve clamping screw and tighten adjusting sleeve clockwise until the worm shaft end play is taken up. Tighten adjusting sleeve clamping screw.



- 4 - Adjust sector shaft end play: Tighten adjusting screw clockwise as far as it will go and back it off  $\frac{1}{8}$  turn.
- 5 - The adjusting nut has to be secured in position by the lock nut after the adjustment has been completed.
- 6 - After having completed adjustments with the car supported on trestles, check the steering for binding by turning the steering wheel in both directions as far as it will go.

### Front Wheel Bearings

The front wheel bearings will occasionally require adjustment. We recommend you to refer this operation to an Authorized VW Workshop, as maladjustment may cause severe damage to the bearings.

If circumstances require the removal of a front brake drum, the front wheel bearings are to be adjusted as outlined below:

Tighten inner nut until the thrust washer can just be moved laterally by a screwdriver and no bearing play can be felt when rocking the brake drum. Incorrect adjustment may ruin the bearings in a very short time.

Finally, secure the nuts by bending down the lock plate.



### Checking and Adjusting Torsion Arm Link Pins

The torsion arm link pins should be checked and, if necessary, readjusted every 5,000 km. (3,000 miles).

The front end of the car should be raised so that the weight is taken off the wheels.

#### Checking

Rock the wheel by hand to check for end play between torsion arm link and torsion arms. If play is present, adjust torsion arm link pins.



### **Adjusting**

- 1 - First grease torsion arm link pins thoroughly.
- 2 - Back off pinch bolts at torsion arm eyes.
- 3 - Tighten torsion arm link pins fully and then turn back 10°-12°.
- 4 - Loosen the pins by tapping lightly on the shaft with a hammer and tighten pinch bolts.

If correct adjustment cannot be effected, the shims are worn and should be replaced in a VW Workshop.

After the torsion arm link pins have been adjusted, it is absolutely necessary to check the toe-in.

### **Checking toe-in**

With the vehicle empty the toe-in should be 2-4 mm. (.08"-.16"). This adjustment of the front wheels can only be carried out satisfactorily in a workshop with the aid of a special gauge. If the wheels are not properly toed-in the result will be bad road holding and excessive tire wear.

### **Convertible Door Windows**

A vertical adjustment of the door windows on Convertibles is possible by stop screws, which are accessible by removing the door trim panels. The lock nut of the stop screw is to be loosened before an adjustment is made.


### **Adjustment of Door Lock**

There is no need for regular adjustment of Volkswagen door locks. In the case of a rattling or jamming door the wedge can easily be adjusted.

- 1 - Check the 3 striker plate screws for proper seating. Tighten if necessary.

Adjust the striker plate so that door and pillars are a flush fit. The lock housing on the door must have about the same clearance at top and bottom when sliding into the striker plate.



- 2 - Hold the adjusting screw by means of a screwdriver and tighten lock nut with a 11 mm. wrench.



- 3 - Turn the adjusting screw to the left if the door is rattling and to the right if it jams. A quarter to half a turn will usually suffice to bring the shoulder for the wedge into the proper position.

- 4 - The locking device is properly adjusted if a resistance can be felt when opening the door with the inside handle. If, however, there is too much resistance or if the door jumps open on its own, turn the shoulder back slightly. This is done by turning the adjusting screw to the right.

- 5 - After adjustment, hold the screw with a screwdriver and tighten lock nut.



### Engine

- 1 - Carburetor
- 2 - Ignition coil
- 3 - Oil cooler
- 4 - Intake manifold
- 5 - Fuel pump
- 6 - Distributor
- 7 - Oil pressure switch
- 8 - Valve
- 9 - Cylinder

- 10 - Piston
- 11 - Heater junction box
- 12 - Oil pressure relief valve
- 13 - Fan housing
- 14 - Fan
- 15 - Throttle ring
- 16 - Generator
- 17 - Flywheel
- 18 - Crankshaft
- 19 - Camshaft
- 20 - Oil pump
- 21 - Muffler (silencer)
- 22 - Oil filler and breather
- 23 - Pre-heating pipe
- 24 - Connecting rod
- 25 - Spark plug
- 26 - Cylinder head
- 27 - Rocker arm
- 28 - Push rod
- 29 - Cam follower
- 30 - Thermostat
- 31 - Oil strainer

# GENERAL DESCRIPTION

## Engine

The engine, located in the rear of the car, is attached by 4 bolts to the recessed flange of the rubber-cushioned transmission case. Two pairs of cylinders are horizontally opposed. Each pair has a common cylinder head made of light alloy. The overhead valves are located in the cylinder head and are operated by the camshaft via cam followers, push rods and rocker arms. The short and counter-balanced crankshaft rests in four special light alloy bearings and is heat-treated at its four points of support. It drives the camshaft by means of helical gears. The connecting rods are fitted with lead-bronze bearings. The pistons are made of aluminium alloy.

A down-draft carburetor with automatic choke and accelerator pump supplies the fuel-air mixture to the cylinders. The engine is equipped with battery ignition.

The spark advance is controlled automatically by a vacuum mechanism.

The oil pump of the pressure lubrication system is driven by the camshaft and sucks the oil from the crankcase through a strainer and pumps it to the various lubrication points via an oil cooler. In cold weather, when the oil is of higher viscosity, an oil pressure relief valve makes it possible for the engine to be lubricated directly, that is, by allowing the oil to by-pass the oil-cooler. The air cooling of the engine is done by means of a fan, which is attached to the extended generator shaft and driven from the crankshaft by an adjustable V-belt. The fan sucks in air through an opening in the fan housing, and the air cools the engine by passing through fins. A thermostat controls and regulates the amount of cooling air and insures well-balanced operating and heating temperatures.

## Chassis

The frame of the VOLKSWAGEN is of pressed steel. The steel floor of the frame is formed in two pieces. These two pieces are spot-welded together with the channel shaped center section of the frame, the forked rear end of which serves to support the transmission and engine unit. The following parts pass through the center of the frame:

Gearshift rod, fuel line, and, in conduits, the cables of hand brake, clutch, throttle, and heating control cables.

The front suspension is an independent parallel arm type, using torsion bar springs. The front axle is bolted to the front end of the frame and consists of two rigidly joined tubes, which carry the torsion bar springs

and the upper and lower arms of the front wheel suspension. A stabilizer is attached to both lower torsion arms. The steering gear with worm, sector and sector shaft acts on the front wheels via a divided tie-rod. A steering damper ensures steering steadiness. The rear axle is of the swinging half axle design. The rear wheels likewise are independently sprung, using one individual torsion bar spring on each side. Double-acting hydraulic shock absorbers in front and rear prevent excessive rebound.

### **Transmission and Rear Axle**

Power from the engine is transmitted to the gears via a dry single-plate clutch. The transmission case incorporates four forward speeds, one reverse, and the differential.

The vehicle is equipped with synchromesh on all forward gears. The gears are helically cut to provide silent operation.

The drive pinion and the ring gear are cut spirally. The two swinging rear axle shafts are flexible supported in the differential housing.

### **Brakes**

The hydraulic brakes operate on all the wheels, and the handbrake, via cables, on the rear wheels.



### **Body**

The basic structure of the VOLKSWAGEN is made of formed steel panels, electrically welded together and strongly reinforced to provide maximum rigidity. Draft-free ventilation by means of vent wings is provided on both door windows. Both front seats can easily be adjusted even when the car is in motion. The front hood lock is released by pulling a knob. The fuel tank and the spare wheel are located underneath the front hood. Luggage space is provided behind the rear seats and under the front hood.

### **Heating System**

Heated air, which is taken from the air flow warmed up by the engine, is emitted through two openings at foot level in the front of the car. For defrosting, two ducts direct heated air to nozzles at the windshield. The heating system can be controlled from the driver's seat by means of a rotary knob situated in front of the hand brake lever.

## Rear Axle and Transmission.



- |                              |                             |                              |
|------------------------------|-----------------------------|------------------------------|
| 1 - Transmission shift lever | 10 - 1st speed              | 18 - Reverse sliding gear    |
| 2 - Bonded rubber mounting   | 11 - Drive pinion           | 19 - Oil filler plug         |
| 3 - Gearshift housing        | 12 - Reverse gear           | 20 - Reverse shaft           |
| 4 - 4th speed                | 13 - Differential pinion    | 21 - Reverse drive gear      |
| 5 - Gear carrier             | 14 - Differential side gear | 22 - Ring gear (Crown wheel) |
| 6 - 3rd speed                | 15 - Clutch release bearing | 23 - Rear axle shaft         |
| 7 - Oil drain plug           | 16 - Main drive shaft, rear | 24 - Fulcrum plate           |
| 8 - 2nd speed                | 17 - Clutch operating shaft | 25 - Differential housing    |
| 9 - Main drive shaft, front  |                             |                              |



## TECHNICAL DATA

### Engine

Design . . . . .	4 Cylinder, 4 Cycle, O.H.V.-Type, in rear of car	
Arrangement of Cylinders . . . . .	Horizontally opposed (Flat Four)	
Bore . . . . .	77 mm. (3.031")	
Stroke . . . . .	64 mm. (2.520")	
Capacity . . . . .	1192 c.c. (72.740 cu. in.)	
Compression Ratio . . . . .	7.0	
Valve Clearance . . . . .	Intake 0.20 mm. (.008")	} to be adjusted when engine is cold
	Exhaust 0.20 mm. (.008")	
Brake Horsepower (SAE) . . . . .	40 at 3900 r.p.m.	
Lubrication . . . . .	Force Feed (Gear Pump) with Oil Cooler	
Oil Capacity . . . . .	Metric - 2.5 liters U.S. - 5.3 pints Imp. - 4.4 pints	
Fuel Pump . . . . .	Diaphragm Type	
Carburetor . . . . .	Down-Draft Type, Solex 28 PICT	
Cooling System . . . . .	Air Cooling by Fan, Thermostat-controlled Air Intake	
Battery . . . . .	6 Volts, 66 Ampere Hours	
Starting Motor . . . . .	Electric, 6 Volts, 0.5 HP.	



Generator . . . . .	Voltage regulating, 6 Volts, 180 Watts at 2500 r.p.m.	
Ignition Distributor . . . . .	Vacuum Spark Advance	
Firing Order . . . . .	1-4-3-2	
Initial Spark Advance . . . . .	10° before T.D.C.	
Breaker Point Gap . . . . .	0.4 mm. (.016")	
Spark Plugs . . . . .	Bosch W 175 T 1 Beru 175/14 AC 43 L or 43 F Auto-Lite AE 6 or AER 6 Champion L 10 S, or L 85 Firestone 147 KLG F 70 Lodge H 14	} 14 mm.
Spark Plug Gap . . . . .	up to 0.7 mm. (.028")	

### Clutch

Design . . . . .	Single Plate, dry
Pedal Free-Play . . . . .	10 to 20 mm. (.4"- .8")

### Transmission

4 Forward Speeds, 1 Reverse

All forward gear synchronized and silent.

Gear Ratios . . . . .	First	3.80 : 1	Third	1.32 : 1
	Second	2.06 : 1	Fourth	0.89 : 1
			Reverse	3.88 : 1

### Rear Axle

Power is transmitted through a spiral drive pinion and ring gear, via two swinging axles to the rear wheels.

Ratio . . . . . 4.375 : 1

Oil Capacity of Transmission

and Rear Axle . . . . .

Metric	- 3.0 liters
U.S.	- 6.3 pints
Imp.	- 5.3 pints

## Chassis

Springs, Front . . . . .	Two Torsion Bars
Rear . . . . .	Two Torsion Bars
Shock Absorbers . . . . .	Double Acting Telescopic Type, Front and Rear
Steering . . . . .	Worm Steering Gear, divided Tie Rod and Hydraulic Steering Damper
Turns of Steering Wheel,	
Lock to Lock . . . . .	2.4
Turning Circle . . . . .	about 11 m. (36 ft.)
Wheels . . . . .	Disc Wheels 4 J x 15, Drop-Center Type
Tires . . . . .	5.60-15, tubeless
Inflation Pressure	
1 to 2 Occupants . . . . .	Front: 1.1 kg./sq. cm. Rear: 1.4 kg./sq. cm. 16 lbs./sq. in.                      20 lbs./sq. in.
3 to 5 Occupants . . . . .	Front: 1.2 kg./sq. cm. Rear: 1.6 kg./sq. cm. 17 lbs./sq. in.                      23 lbs./sq. in.
Wheel Base . . . . .	2,400 mm. (94.5 in.)
Track (Tread) . . . . .	Front: 1,305 mm. (51.4 in.) Rear: 1,288 mm. (50.7")
Toe-in (car unloaded) . . . . .	2 to 4 mm. (0.08 in. to 0.16 in.)

## Brakes

Foot Brake . . . . .	Hydraulic Brake, Operating on All Wheels
Hand Brake . . . . .	Mechanical, Operating on Rear Wheels

## Dimensions and Weights

Length . . . . .	4,070 mm. (13 ft. 4 in.)
Width . . . . .	1,540 mm. (5 ft. 0.6 in.)
Height . . . . .	1,500 mm. (4 ft. 11 in.)
Ground Clearance . . . . .	152 mm. (6.0 in.)

	Sedan	Convertible
Unladen Weight, Ready for Use . . . . .	740 kg. (1,631 lbs.)	800 kg. (1,764 lbs.)
Max. Load . . . . .	380 kg. ( 838 lbs.)	360 kg. ( 793 lbs.)
Permissible Total Weight . . . . .	1,120 kg. (2,469 lbs.)	1,160 kg. (2,557 lbs.)
Max. Load on Front Axle . . . . .	450 kg. ( 992 lbs.)	480 kg. (1,058 lbs.)
Max. Load on Rear Axle . . . . .	670 kg. (1,477 lbs.)	680 kg. (1,499 lbs.)

## Fuel Consumption

### Standard Consumption

according to DIN 70030 . . . Metric - 7.5 liters per 100 km.  
 U.S. - 31.5 miles per gallon  
 Imp. - 37.5 miles per gallon

(Consumption plus 10% at half the load and at a steady 3/4 of top speed  
 86 k.p.h./53 m.p.h. on level road.)

Fuel . . . . . Octane Number 76 (Res. F 1)  
 Oil Consumption . . . . . 0.3-1.0 liter per 1,000 km. (600 miles)  
 1.0-3.4 U.S. pints per 1,000 miles  
 0.9-2.8 Imp. pints per 1,000 miles

## Refill Requirements

Fuel Tank . . . . . 40 liters (10.6 U.S. gall.; 8.8 Imp. gall.),  
 of these 5 liters (1.3 U.S. gall., 1.1 Imp.  
 gall.) as reserve.  
 Engine . . . . . 2.5 liters (5.3 U.S. pints; 4.4 Imp. pints)  
 Rear Axle and Transmission. 2.5 liters (5.3 U.S. pints; 4.4 Imp. pints)  
 Steering Gear Case . . . . . 0.125 liter (0.26 U.S. pint; 0.22 Imp. pint)  
 Brakes . . . . . 0.25 liter (0.53 U.S. pint; 0.44 Imp. pint)  
 Container for windshield  
 washer . . . . . approx. 1 liter (1 qt.)  
 Oil bath air cleaner . . . . . 0.25 liter (0.53 U.S. pint; 0.44 Imp. pint)


## Performance

Maximum and Cruising Speed 115 k. p. h. (72 m. p. h.)

	Sedan	Convertible
Hill-Climbing Ability . . . . .	First Gear 43.5 %	39.0%
	Second Gear 22.5 %	20.5%
	Third Gear 13.5 %	12.0%
	Fourth Gear 7.5 %	6.5%

## Bulb Chart V = Volts, W = Watts

Light Description	Description of Bulb (according to German Standard DIN 72601)	Spare Part No.
Headlights . . . . .	A 6 V 45/40 W	N 177051
Parking Lights . . . . .	HL 6 V 4 W	N 177171
Stop/Tail/Flashing		
Indicator Lights . . . . .	S 6 V 18/5 W	N 177371
License Plate Light . . . . .	G 6 V 5 W	N 177181
Instrument Lights . . . . .	J 6 V 1.2 W	N 177221
Interior Light . . . . .	K 6 V 10 W	N 177231
Flashing Indicator Light . . . . .	R 6 V 18 W	N 177311



# LUBRICATION CHART

500 km. 300 miles 2,500 km. 1,500 miles 5,000 km. 3,000 miles	No.	Lubrication Points	Lubricant	Every
	1/8	Transmission: Clean magnetic oil drain plugs. Check oil level		
	2	Engine: Check oil level	M	<div style="background-color: #4a86e8; color: white; padding: 5px; text-align: center;"> <b>2,500 km. 1,500 miles</b> </div>
	3	Torsion arms	F	
	4	King pins and torsion arm link pins	F	
	5	Tie rod ends	F	
		Door hinges	M	
	6	Engine: Change oil, clean oil strainer	M	
	7	Clean air cleaner	M	
	8	Transmission: Check oil level	G	
	9	Steering gear: Check oil level	G	
	10	Brake cables	F	
	11	Pedal linkage	F	
	12	Carburetor controls, shafts, fast idle cam	M	
		Door and hood locks	F	<div style="background-color: #4a86e8; color: white; padding: 5px; text-align: center;"> <b>5,000 km. 3,000 miles</b> </div>
	1	Transmission: Change oil, clean magnetic oil drain plugs	G	<div style="background-color: #4a86e8; color: white; padding: 5px; text-align: center;"> <b>25,000 km. 15,000 miles</b> </div>

## LUBRICANTS

Lubricant	Lubrication Points		Specifications			
			Temperature			
			°C	°F		
Engine oil (HD oil for spark ignition engines)	Engine, oil bath air cleaner, carburetor linkage, door hinges, Felt ring in contact breaker base plate	M	above	+30	+86	SAE 30
			from	0	+32	SAE 20 or
			up to	+30	+86	SAE 20 W
			below	0	+32	SAE 10 W
			below	-25	-13	SAE 5 W
Transmission Oil	Transmission	G	above	0	+32	SAE 90
	Steering gear		G	below	0	+32
						SAE 90
Universal grease	Torsion arms, king pins and torsion arm link pins, tie rod ends, brake cables, pedal linkage, door and hood locks, breaker arm fiber block in distributor	F	cold-resistant water-repellent high pressure grease			
Lithium grease	Front wheel bearings	W	Multi-purpose grease			

# MAINTENANCE CHART

500 km. 300 miles	5,000 km. 3,000 miles	Operation	Every
		Check adjustment of automatic air intake control	
		Check for tightness: Nuts and bolts on engine, exhaust system, intake manifold carburetor and fuel pump	
		Check for tightness: Nuts and bolts on chassis, body, rear axle, front axle, and steering	
		Check tire pressures and wheel mounting bolts for tightness	
		Check fan belt	<b>5,000 km. 3,000 miles</b>
		Check throttle ring for proper contact on fan housing	
		Clean fuel pump filter	
		Lubricate felt ring in contact breaker base plate	
		If necessary, clean breaker points, grease breaker arm fiber block	
		Check contact breaker points and timing	
		Check valve clearance	
		Clean and check spark plugs. Check compression	
		Check rear axle and engine for leaks	
		Check intake and exhaust systems for damage	
		Check clutch pedal free-play	
		Check steering adjustment	
		Check torsion arm link pins, front wheel bearing play, tie rod ends, steering damper mounting and toe-in	
		Interchange tires and check tire pressures	
		Check foot hand brake functionally	
		Check thickness of brake linings through inspection hole	
		Check shock absorbers for secure mounting	
		Check battery	
		Check for correct operation: headlights, tail and stop lights, warning lamps, horn, windshield wipers and flashing indicators	
		Check adjustment of door lock striker plates	
		Road-test the vehicle, check idling adjustment	
		Clean, grease and adjust front wheel bearings	<b>50,000 km. 30,000 miles</b>

# INDEX

	Page		Page
Accelerating – correct and wrong . . . . .	26	Driving the Volkswagen . . . . .	15
Accelerator pedal . . . . .	7	Driving down-hill . . . . .	17
– accelerating . . . . .	27	<b>Economy</b> . . . . .	27
Accessories . . . . .	III	<b>Engine – compression ratio</b> . . . . .	78
Air cleaner – cleaning . . . . .	53	– description . . . . .	75
Ash tray . . . . .	20	– design . . . . .	78
<b>Battery – maintenance</b> . . . . .	60	– lubrication (oil change) . . . . .	35
– care in winter . . . . .	34	– oil change in winter . . . . .	32
<b>Body – airing the interior</b> . . . . .	52	– oil level . . . . .	10
– description . . . . .	76	– oil strainer . . . . .	36
<b>Brakes – adjusting</b> . . . . .	67	– speed . . . . .	81
– application . . . . .	17	– sectional view . . . . .	74
– bleeding . . . . .	67	– technical data . . . . .	78
– care in winter . . . . .	34	– type of oil . . . . .	32
– checking . . . . .	12	<b>Fan belt – adjusting</b> . . . . .	54
– description . . . . .	76	– checking tension . . . . .	10
<b>Brake pedal</b> . . . . .	7	<b>Flashing indicator switch</b> . . . . .	7
<b>Breaking-in (running-in) period</b> . . . . .	26	<b>Foot brake – adjusting</b> . . . . .	67/69
<b>Carburetor adjusting</b> . . . . .	56	– description . . . . .	76
– type . . . . .	78	<b>Front axle – description</b> . . . . .	75
<b>Care of the car</b> . . . . .	47	– lubrication . . . . .	40
<b>Chassis – care in winter</b> . . . . .	33	– technical data . . . . .	80
– description . . . . .	75	<b>Front seats – adjustment</b> . . . . .	18
<b>Chassis number</b> . . . . .	8	– lubrication of seat runners . . . . .	42
<b>Chromium-plated parts – care</b> . . . . .	51	<b>Front wheel bearings – adjusting</b> . . . . .	71
<b>Climbing ability</b> . . . . .	81	– lubrication . . . . .	40
<b>Clutch – design</b> . . . . .	79	<b>Fuel consumption</b> . . . . .	81
– pedal . . . . .	7	<b>Fuel filter-cleaning</b> . . . . .	55/56
– pedal free-play . . . . .	79	<b>Fuel tank – capacity</b> . . . . .	11/81
<b>Cold weather hints</b> . . . . .	32	– reserve . . . . .	11
<b>Compression</b> . . . . .	59	<b>Fuel tap positions</b> . . . . .	11
<b>Controls and instruments</b> . . . . .	7	<b>Fuse boxes</b> . . . . .	66
<b>Cooling of engine</b> . . . . .	78	<b>Fuses-replacing</b> . . . . .	65
<b>Dimensions – overall</b> . . . . .	80	<b>Gear lever</b> . . . . .	7
<b>Dimmer switch – headlight</b> . . . . .	7	<b>Gear shifting on gradients</b> . . . . .	27
<b>Doors – care of weather strips</b> . . . . .	52	<b>Generator</b> . . . . .	79
– inside handle . . . . .	7	<b>Ground clearance</b> . . . . .	80
– lubrication points . . . . .	41		

	Page		Page
<b>Hand brake – adjusting</b> . . . . .	69	<b>Parking your car</b> . . . . .	31
– description . . . . .	76	<b>Passing other cars</b> . . . . .	30
<b>Headlight – aiming</b> . . . . .	62	<b>Practical driving</b> . . . . .	26
– changing bulb . . . . .	63	<b>Ratios – rear axle</b> . . . . .	79
<b>Heating – description</b> . . . . .	76	– transmission . . . . .	79
– operation . . . . .	32	<b>Rear axle – description</b> . . . . .	76
<b>Hood lock – control knob</b> . . . . .	7	– technical data . . . . .	79
– Convertible . . . . .	22	– transmission of power . . . . .	79
<b>Horn half ring</b> . . . . .	7	<b>Rear seat back</b> . . . . .	21
<b>Identification plate</b> . . . . .	8	<b>Rear view mirror</b> . . . . .	30
<b>Idling – checking and adjusting</b> . . . . .	56	<b>Reverse gear</b> . . . . .	16
<b>Ignition – breaker point gap</b> . . . . .	59	<b>Safety in traffic</b> . . . . .	30
– distributor . . . . .	79	<b>Seat adjustment</b> . . . . .	18
– firing order . . . . .	79	<b>Sectional view with explanations</b> . . . . .	88
– lubrication of distributor . . . . .	38	<b>Shifting gears</b> . . . . .	15
– timing . . . . .	59	<b>Shock absorbers – design</b> . . . . .	80
<b>Instrument light</b> . . . . .	12	<b>Spare wheel</b> . . . . .	45
<b>Interior light</b> . . . . .	20	<b>Spark plugs – checking and cleaning</b> . . . . .	58
<b>Jack – application</b> . . . . .	45	– gap . . . . .	58
– location . . . . .	22	– removal . . . . .	58
<b>Key – doors and ignition</b> . . . . .	8	<b>Speedometer</b> . . . . .	7
<b>License plate light – replacing bulb</b> . . . . .	64	<b>Speed ranges</b> . . . . .	26
<b>Light switch – positions</b> . . . . .	12	<b>Spots – removal</b> . . . . .	49
<b>Lubricants</b> . . . . .	83	<b>Starting – danger in enclosed spaces</b> . . . . .	14
<b>Lubrication</b> . . . . .	35	– in winter . . . . .	13
<b>Lubrication chart</b> . . . . .	83	– with temperatures under freezing point . . . . .	14
<b>Maintenance</b> . . . . .	53	– with temperatures above freezing point . . . . .	14
<b>Maintenance chart</b> . . . . .	84	<b>Starting motor</b> . . . . .	78
<b>Maximum output</b> . . . . .	78	<b>Steering – adjusting</b> . . . . .	70
<b>Maximum speed</b> . . . . .	81	– type . . . . .	80
<b>Non-skid chains</b> . . . . .	34	<b>Stop light – bulb replacement</b> . . . . .	64
<b>Oil consumption</b> . . . . .	81	– checking . . . . .	12
<b>Oil level – engine</b> . . . . .	10	<b>Stopping the car – general</b> . . . . .	17
– steering gear . . . . .	39	– temporarily . . . . .	30
– transmission . . . . .	38	<b>Sun roof – cleaning</b> . . . . .	50
<b>Paintwork – preservation</b> . . . . .	47	– opening and closing . . . . .	23
– polishing . . . . .	48	<b>Suspension – front</b> . . . . .	80
		– rear . . . . .	80



	Page		Page
Tail light - replacing bulb . . . . .	64	Valves - adjusting . . . . .	57
Technical data . . . . .	78	- arrangement . . . . .	78
Tires - inflation pressure . . . . .	12	- clearance . . . . .	78
- maintenance . . . . .	44	Vent wing . . . . .	7
- M+S tires . . . . .	34	<b>Warning lights-flashing indicator . . . . .</b>	<b>29</b>
- size . . . . .	80	- generator and cooling . . . . .	29
- wear . . . . .	43	- headlight . . . . .	29
Toe-in of front wheels . . . . .	80	- oil pressure . . . . .	29
Tools and accessories . . . . .	III	- replacing bulbs . . . . .	64
Track (tread) . . . . .	80	Washing your car . . . . .	47
Transmission - description . . . . .	76	Weights . . . . .	80
- oil change and capacity . . . . .	38	Wheel base . . . . .	80
- sectional view . . . . .	77	Wheels - balancing . . . . .	44
- technical data . . . . .	79	- changing . . . . .	45
Turning circle . . . . .	80	- rim size . . . . .	80
Type of fuel . . . . .	11	Window regulator - lubrication . . . . .	41/42
<b>Upholstery - care of cloth . . . . .</b>	<b>51</b>	Window regulator handle . . . . .	7
- leatherette . . . . .	51	Window weather strips - care . . . . .	52
- leather . . . . .	52	Windshield wiper switch . . . . .	7



## VW SEDAN, SECTIONED

- 1 Spare tire and wheel
- 2 Brake fluid reservoir
- 3 Steering gear
- 4 Front axle and square torsion bars
- 5 Fuel tank
- 6 Fuel tap
- 7 Brake master cylinder
- 8 Pedal linkage
- 9 Speedometer
- 10 Gear lever
- 11 Heating control
- 12 Flashing indicator switch
- 13 Hand brake lever
- 14 Vent wing handle
- 15 Battery
- 16 Socket for car jack
- 17 Rear torsion bar
- 18 Transmission
- 19 Starting motor
- 20 Differential
- 21 Clutch
- 22 Shock absorber
- 23 Crankshaft
- 24 Camshaft
- 25 Oil strainer
- 26 Fan housing
- 27 Oil pump
- 28 Generator
- 29 Muffler (Silencer)
- 30 Carburetor
- 31 Oil bath air cleaner


## **Tools and Accessories**

- 1 Spare Fan Belt
- 1 Tool Roll
- 1 Spare Tire and Wheel, complete
- 1 Jack
- 1 Hub Cap Removal Tool
- 1 Combination Pliers
- 1 Screwdriver 0.8
- 1 Screwdriver 0.5
- 1 Open End Wrench 8/12 mm.
- 1 Socket Wrench for Spark Plug, Fan Pulley Nut, Wheel Disc Bolt
- 1 Socket Wrench 14 mm.
- 1 Rod for Socket Wrench and Jack

Copyright. All rights reserved.

May not be reproduced or translated in whole  
or in part without the written consent of  
Volkswagenwerk.

Specification subject to alteration without notice.



- 1
- 2
- 3
- 4
- 5
- 6
- 7
- 8
- 9
- 10
- 11
- 12
- 13
- 14
- 15
- 16
- 17
- 18
- 19
- 20
- 21
- 22
- 23
- 24
- 25
- 26
- 27
- 28
- 29
- 30
- 31

