

VOLKSWAGENWERK A. G.




# Troubleshooting Guide

Electronic Fuel Injection  
AFC (air flow controlled)

Types 1 and 2  
(from November 1974)

How to use this guide




More Troubleshooting help

		Ordering No.
Engine	MPC fuel injection	
	Type 3 all	
	Type 4 autom. transm. up to Oct. '73	
	Type 4 man. transm. ....	W 42-00-4950-1
	AFC fuel injection	
	Type 4 autom. transm. from Nov. '73 .....	W 42-00-4946-1
	AFC fuel injection	
	Types 1 and 2 up to model year '75 .....	W 42-00-4952-1
	AFC fuel injection	
	Type 1 model year 1976 .....	W 42-00-5954-1
Automatic Transmission	AFC fuel injection	
	Type 2 model year 1976 .....	W 42-00-5955-1
	CIS fuel injection	
	Dasher, Rabbit, Scirocco, AUDI 100, AUDI Fox ....	W 42-00-6957-1
	Carbureted Engines (air and water cooled) .....	W 42-00-4947-1
	Carburetor-equipped Engines	
	Rabbit/Scirocco Model 1976 .....	W 42-00-6956-1
	Automatic transmission 003 troubleshooting	
	Types 2, 3, 4 and Dasher .....	W 42-00-3945-1
	Automatic transmission 010 troubleshooting	
Heater	Rabbit/Scirocco, Dasher, Audi Fox, Audi 100 LS, VW Transporter .....	W 42-00-5953-1
	Automatic transmission 003 and 010 troubleshooting	
	Parts wear comparison .....	W 42-00-6958-1
	Heater Type 4 1971/72 .....	W 42-00-2940-1
	Heater Type 4 1973/74 .....	W 42-00-3940-1
	Air conditioner, factory installed	
	Rabbit/Scirocco .....	W 42-00-4122-1
	Air conditioner, factory installed	
	Dasher .....	W 42-03-5146-1
	Air conditioner, factory installed	
Air Conditioner	Audi Fox, Audi 100 .....	W 42-55-5146-1

# Wiring diagram

Wiring diagram Types 1 and 2



Engine does not start 3  
Cold engine does not start 15  
Hot engine does not start 19  
Engine starts–stalls after short time 23

Idle speed too high 27  
Idle irregular 33

Hesitation 37

Poor output / performance 41

Fuel consumption too high 49





Engine misfiring 53

CO value too high 57  
Current flow diagram 60

**Note**

Following defects may be found despite visible sparking at plug connectors.

- Distributor cap damp, cracked, burnt by tracking
- Rotor arm defective
- Loose connections on coil
- Spark plugs connectors defective
- Ignition timing off (breaker points)
- Ignition cables badly connected
- Arcing at ignition cables on distributor (through rubber caps)
- Voltage at terminal 15 on coil too low (minimum voltage = 9 Volts when starting)
- Condenser defective



(continued from page 57)


Injector or cold start valve leaking	
<ul style="list-style-type: none"><li>● Pressure gauge is connected</li><li>● Pull wire off coil terminal 1</li><li>● Operate starter briefly</li><li>● Pressure should not drop quickly to 0 psi</li></ul>	
Pressure remains constant	Pressure drops quickly

Air flow obstructed	
<b>Possible causes / checking sequence</b> <ul style="list-style-type: none"><li>● Check air cleaner for dirt</li><li>● Check whether air flow is obstructed by incorrect gasket between intake manifold and cylinder head (if in doubt: renew gasket)</li></ul>	
No trouble located	Trouble located and corrected; CO value OK



<ul style="list-style-type: none"><li>● Remove injector or cold start valve but leave connected to the ring main</li><li>● Wire to terminal 1 of coil is disconnected</li><li>● Operate starter briefly</li><li>● Replace leaking valve</li></ul>
---

<b>Other possible causes</b> <ul style="list-style-type: none"><li>● Valve clearances incorrect:</li><li>● Poor combustion due to defective spark plugs</li><li>● Compression low or uneven</li><li>● CO influenced by crankcase ventilation:<ul style="list-style-type: none"><li>a) excessive oil in crankcase</li><li>b) oil being diluted by fuel (particularly in winter)</li></ul></li></ul> Correct any troubles located
---

- Test condition:
- No mistakes in starting procedure
  - Fuel in tank
  - Starter speed is normal (battery voltage)



**Checking / adjusting valve clearances**  
It is important that cylinder heads have cooled down to ambient temperature before checking or adjusting valve clearances.  
Particularly critical is when the engine itself is still cold after a short drive but the cylinder heads have become hot (e. g. when vehicle has been driven from parking lot into workshop shortly before adjustment)



- Test condition:
- Ignition timing correct
  - Engine oil temperature between 50° and 70° C (122° and 157° F)

Pressure in ring main too high

Connect pressure gauge

- Pull wire off coil terminal 1
- Operate starter
- Pressure should be 2.5 kg/cm<sup>2</sup> (35 psi)

Pressure is correctPressure too high

Pressure regulator not working

- Connect wire to coil terminal 1
- Run engine at idling speed
- Pressure should drop to approx. 2.0 kg/cm<sup>2</sup> (28 psi)

Pressure dropsPressure does not drop

Replace pressure regulator

If pressure is still too high, check if return line between pressure regulator and fuel tank is kinked or blocked

Resistance of temperature sensor in cylinder head too high



- Run engine until oil temperature is above 80° C (176° F)
- Pull wire off temperature sensor
- Connect ohmmeter
- Resistance should be less than 300 Ω

Resistance is correctResistance is well above specified value

Check hose connections between intake air distributor and pressure regulator. If OK, replace pressure regulator

- Possible causes:
- Resistance in thread in cylinder head too high due to corrosion
  - Temperature sensor defective

go to page 59



(continued from page 3)

Temperature sensor on cylinder head has no continuity or is shorted	
<ul style="list-style-type: none"><li>● Disconnect wire from temperature sensor.</li><li>● Connect ohmmeter</li></ul> Resistance about 2.5k $\Omega$ (at 20°C/68°F temperature)	
Measured resistance is as specified	Ohmmeter shows 0 $\Omega$ or $\infty \Omega$

Replace temperature sensor


Engine floods due to defective cold start valve	
<ul style="list-style-type: none"><li>● Pull connector off cold start valve.</li><li>● Start engine with throttle fully open because plugs may be wet.</li></ul>	
Engine does not start	Engine starts

Replace thermo time switch

Engine floods due to leaky cold start valve	
<ul style="list-style-type: none"><li>● Detach cold start valve from intake air distributor but leave it connected to the ring main.</li><li>● Pull connector off cold start valve.</li><li>● Pull wire off terminal 1 on coil.</li><li>● Operate starter.</li></ul>	
Valve does not leak	Valve leaks

Replace cold start valve

go to page 13



(continued from page 53)

Poor terminal or ground connections in the injection system	
Check all connections systematically for proper fit and corrosion	
No defects	Defects found and rectified

Control unit cuts out intermittently	
<ul style="list-style-type: none"><li>● Remove control unit but leave it connected</li><li>● Tap control unit with hand to check for loose soldered joints</li><li>● Move wiring to check for breaks in wires</li></ul>	
No defects	Defects found and corrected


Faulty contact in intake air sensor	
<ul style="list-style-type: none"><li>● Install new intake air sensor for testing</li><li>● Road test vehicle</li></ul>	
Still misfiring	Not misfiring


Alternator or regulator defective	
Road test vehicle with V belt removed	
Still misfiring	Not misfiring

Fuel supply inadequate
<b>Possible troubles:</b> <ul style="list-style-type: none"><li>● Fuel filter blocked</li><li>● Tank strainers blocked</li><li>● Rust in fuel tank</li><li>● Injectors blocked</li><li>● Tank ventilation blocked</li></ul>
Eliminate defect

Install another regulator, install belt again and road test vehicle
If fault still exists: Repair or replace alternator










**Note**


If engine stalls only after "coasting" engine is drawing in oil, possibly through crankcase breather or valve guides, (noticeable by blue smoke being emitted during "coasting").  
In such cases:  
Check crankcase breather or, if necessary check valve guides for wear



(continued from page 3)



(continued from page 49)



Resistance of temperature sensor in cylinder head too high	
<ul style="list-style-type: none"><li>● Run engine until oil temperature is above 80° C (176° F)</li><li>● Pull wire off temperature sensor</li><li>● Connect ohmmeter</li></ul> Specified resistance: Less then 300 Ω	
Resistance OK	Resistance is well above specified value


- Possible causes:
- Resistance in cylinder head thread due to rust
  - Temperature sensor defective

Cold start valve leaking	
Check cold start valve for leakage	
No leakage	Leakage found and eliminated



Injector open continuously	
<ul style="list-style-type: none"><li>● Remove injectors but leave them attached to the ring main</li><li>● Pull wire off coil terminal 1</li><li>● Operate starter briefly and check if more than two drops leak from each injector per minute</li></ul>	
Injectors OK	Injector leaking

Control unit defective
Replace control unit

Replace injector



Type 1 - in rear luggage compartment  
Type 2 - next to battery



**Note**

- Detach cold start valve from intake air distributor but leave it connected to the ring main
- Operate starter briefly and check if more than two drops leak from valve per minute.

**Warning**  
Fire hazard

Double relay defective

- Connect test light between center slot in moulded connector of series resistance and vehicle ground.
- Switch ignition on

Test light lights up	Test light does not light up
----------------------	------------------------------

Check wire between series resistance and double relay terminal 88b, including connections.  
If OK, replace double relay

No triggering impulse from coil terminal 1

- Pull multi-pin connector off control unit.
- Connect test light between terminal 1 and vehicle ground.
- Operate starter  
Test light should flicker

Test light flickers	Test light does not flicker
---------------------	-----------------------------

**Possible troubles:**

- Break in wire between terminal 1 on distributor and terminal 1 on control unit multi-pin connector
- Breaker contacts in distributor defective or incorrectly adjusted
- Condenser shorting to ground
- Coil defective

Control unit not grounded

- Switch ignition on
- Test voltage between the following terminals on multi-pin connector of control unit.
  - between 10 and 5
  - between 10 and 16
  - between 10 and 17


Test light lights up	Test light does not light up
----------------------	------------------------------

**Possible troubles:**

- Check wiring to control ground connection
  - Type 1 – on top of alternator
  - Type 2 – on top of crankcase
- Break in wire between multi-pin connector terminal 10 and double relay terminal 88b.

Control unit defective

Replace control unit



## Test condition:

- Standard tire size and type
- Air cleaner insert clean
- Wheels turning freely (brakes, wheel bearings)
- Ignition timing correct
- Road test has shown clearly that the fuel consumption is too high

Pressure in ring main too high	
<ul style="list-style-type: none"> <li>● Connect pressure gauge</li> <li>● Pull wire off coil terminal 1</li> <li>● Operate starter</li> </ul> Specified pressure: 2.5 kg/cm <sup>2</sup> (35 psi)	
Pressure OK	Pressure much higher

Pressure regulator not working	
<ul style="list-style-type: none"> <li>● Connect wire to coil terminal 1 again</li> <li>● Run engine at idling speed</li> <li>● Pressure must drop to about 2.0 kg/cm<sup>2</sup> (28 psi)</li> </ul>	
Pressure drops	Pressure does not drop

Engine warms up too slow	
Check thermostat and adjustment of cooling air regulation	
No defects	Defect found and corrected



go to  
page 51

Replace pressure regulator

If pressure is still too high, check if  
return line between pressure regulator  
and tank is kinked or blocked



Check hose between intake air  
distributor and pressure regulator,  
if OK, replace pressure regulator

(continued from page 5)



Starting engine

- Selector lever or gearshift lever in neutral
- Do **not** press accelerator pedal  
This holds true for a cold engine and an engine at operating temperature no matter what the outside temperature is.
- Switch on ignition and start engine
- At outside temperatures below 0° C (32° F) press clutch pedal before starting




Check resistance with Ohmmeter

Check resistance with Ohmmeter

A – Resistance in each ignition cable with plug connector = max. 10k Ω

B – Resistance for rotor = max. 10kΩ



(continued from page 45)

Fuel pressure in ring main too low at full throttle

- Pull off hose between intake air distributor and pressure regulator
- Measure pressure in ring main with a pressure gauge
  - a) At idling speed (specified pressure 2.5 kg/cm²/35 psi)
  - b) At full throttle (specified pressure 2.5 kg/cm²/35 psi)

Pressure at idling and full throttle about 2.5 kg/cm² (35 psi)	Pressure drops noticeably at full throttle	Pressure same at idling and full throttle but too low
--	--	---

Control unit defective

- Try another control unit
- Road test vehicle

Output not OK	Output OK
---------------	-----------

Further possible causes:

- Excessive roll resistance due to wheel toe being badly out of adjustment
- Transmission or final drive tight
- Resistance in EGR system too high (muffler, catalytic converter)

Replace pressure regulator



Fuel supply inadequate

Possible causes:



- Fuel line kinked
- Fuel filter blocked
- Tank strainer blocked
- Corrosion in fuel tank
- Pump not delivering sufficient fuel

Correct defects






(continued from page 43)



Full throttle contact in throttle valve switch not closing	
<ul style="list-style-type: none"><li>● Pull multi-pin connector off control unit</li><li>● Connect ohmmeter between terminals 3 and 18</li><li>● Open throttle fully, ohmmeter reading must change from <math>\infty \Omega</math> to <math>0 \Omega</math></li></ul>	
Reading changes to $0 \Omega$	Reading remains at $\infty \Omega$



Test instructions

a. Thermo-time switch and wiring

- Engine ambient temperature must be below  $10^{\circ}\text{C}$  ( $50^{\circ}\text{F}$ )
- Pull connector off cold start valve
- Connect test light
- Pull off wire from terminal 1 on coil
- Operate starter: Test light should light up brightly at first and then go noticeably dimmer after not more than 11 seconds

b. Cold start valve

- Connect pressure gauge in the ring main
- Operate starter briefly to build up fuel pressure
- Pull connector off cold start valve
- At valve connect one terminal to ground, the other terminal to terminal 15 on coil, using jumper wires
- Turn on ignition. Fuel pressure should slowly drop

Electrical fault in intake sensor	
<ul style="list-style-type: none"><li>● Pull connector off intake air sensor</li><li>● Connect an ohmmeter to terminals 6 and 9 on intake air sensor (resistance 200 to <math>400 \Omega</math>)</li><li>● Measure on terminals 7 and 8 (resistance 120 to <math>200 \Omega</math>)</li></ul>	
Resistance OK	Resistance not OK


Break in wiring to throttle valve switch or throttle valve switch defective  
Eliminate defect


Mechanical fault in intake air sensor	
<ul style="list-style-type: none"><li>● Remove intake air sensor</li><li>● Check if pressure flap is jamming or stiff in operation, in case of doubt, compare with a new part</li></ul>	
Flap is OK	Flap jams or is stiff in operation

Replace intake air sensor


go to  
page 47

Replace intake air sensor, road test vehicle





Type 1 – in rear luggage compartment  
Type 2 – next to battery




(continued from page 15)



Break in wire to starter terminal 50	
<ul style="list-style-type: none"><li>● connect test light between terminals 86a and 85 on double relay</li><li>● operate starter</li></ul>	
Test light lights up	Test light does not light up

Fault in cold start device	
<b>Possible troubles:</b> <ul style="list-style-type: none"><li>● Cold start valve wire detached from terminal 50 of solenoid</li><li>● Wire detached from thermo-time switch</li><li>● Cold start valve or thermo-time switch defective Replace cold start valve or thermo-time switch as necessary</li></ul>	
No defects	Defects found and eliminated

Check wire between starter terminal 50 and double relay
Wire routing: Type 1 – wire connector underneath rear seat bench Type 2 – direct Eliminate defects

If you have not found any faults so far the trouble involved is not a typical cold starting trouble Continue to find out the trouble under "Engine does not start"
---





**Note**  
**Full spark advance** is essential if top speed is to be achieved; therefore check that prescribed full spark advance value is being reached (see table in Workshop Manual "M", chapter "Ignition System")

**Test condition:**

- Correct starting procedure
- Fuel in tank

Valve clearance incorrect	
<ul style="list-style-type: none"><li>● Adjust valves properly with <b>engine cold</b></li><li>● Warmup engine and carry out starting tests</li></ul>	
Engine difficult to start	Engine starts normally

Pressure in ring main too high (mixture too rich)

- Pull vacuum hose off pressure regulator
- Measure pressure with gauge while operating starter (Specified value: 2.5 kg/cm<sup>2</sup>/35 psi)

Pressure is OK (2.5 kg/cm <sup>2</sup> /35 psi)	Pressure is above 2.5 ± 0.2 kg/cm <sup>2</sup> (35 ± 2.8 psi)
---	---

Resistance of cylinder head temperature sensor too high

- Engine **hot**, oil temperature above 80° C (176° F)
- Pull wire off temperature sensor
- Connect ohmmeter
- Resistance less than 300 Ω

Resistance is as specified	Resistance above specified value
----------------------------	----------------------------------

Replace temperature sensor


go to page 21

Pressure regulator defective

- Replace pressure regulator
- Measure fuel pressure

Pressure still too high	Pressure OK. (2.5 kg/cm <sup>2</sup> / 35 psi)
-------------------------	--

Return line between pressure regulator and fuel tank blocked or kinked  
Eliminate defect



**Test instructions**


a. **Thermo-time switch**

- Pull connector off cold start valve
- Connect test light as shown
- Operate starter, test light must not light up

b. **Cold start valve**

- Pull connector off cold start valve
- Detach cold start valve from intake air distributor but leave it connected to the ring main
- Pull wire off coil terminal 1
- Operate starter and check if valve leaks

**Warning**  
Fire hazard



**Test conditions**

- Speedometer reading normal
- Tire sizes and types of tire are to standard specifications
- Wheels rotate freely (brakes, wheel bearings!)
- Clutch and clutch play OK
- No accessories which could reduce top speed (roof rack etc.)
- Break-in period completed (from approx. 3000 miles according to driving style and conditions under which car had been driven).

**Faults in basic engine settings**

- Check accelerator cable adjustment (Throttle must be fully open with pedal at full throttle)
- Check valve clearance with engine cold, adjust if necessary
- Check ignition timing, adjust if necessary
- Check intake air preheating (with engine warm, cold air must be drawn in)
- Check spark plugs for:
  - a) dampness (inside and outside)
  - b) dirt
  - c) burning (heat range)
  - d) electrode gap
  - e) damage
- Check compression

No trouble located	Trouble located and corrected
--------------------	-------------------------------

Road test	
Performance not OK	Performance OK

Contact in throttle valve switch does not operate

- Pull off connector on EGR valve
- Connect test light
- Operate throttle valve (Test light must light up at idle and full throttle position)

Test light lights up	Test light does not light up
----------------------	------------------------------

Replace EGR valve

Check wire to throttle valve switch, if OK replace throttle valve switch

**Exhaust gas recirculates at full throttle**

- Switch on ignition
- Operate throttle valve. EGR valve must click if throttle valve is opened approx. 11° and 75°

EGR valve clicks	EGR valve does not click
------------------	--------------------------

go to page 43



**Speed table**  
– for a 1 mile stretch –

Seconds	mph
58	62
55	65
52	69
48	75
45	80
43	85
40	90
38	95
36	100




**Road testing instruction**

- Increase tire pressure to 3 psi above normal tire pressure
- Engine and transmission must be warm
- Level, dry asphalt road surface
- Normal wind conditions
- Take average readings from one run in each direction
- Check maximum speed where legally permitted on a measured test stretch (1 mile) with a stop watch
- Find actual speed from speed table and compare with speedometer to find variation



**Note**  
If the compression is uneven or too low on a relatively new engine:  
check/adjust valve clearance with cold engine  
After 300 miles recheck compression; if still low, repair engine



(continued from page 37)











Type 1

Type 2






Operating instructions

To warm engine up quickly to normal operating temperature drive off immediately after starting engine. If the cold engine runs too long at idle it tends to stall for some time particularly when weather conditions are cold or damp

Note

- Following defects may be found despite visible sparking at plug connectors:
- Distributor cap (damp, cracked, burnt by tracking)
  - Rotor defective
  - Loose connections on coil
  - Spark plugs or connectors defective
  - Ignition timing off (breaker points)
  - Ignition leads badly connected
  - Arcing at ignition cables on distributor (through rubber caps)
  - Voltage at terminal 15 on coil too low (minimum = 9 volts)
  - Condenser faulty



(continued from page 23)

Resistance of temperature sensor on cylinder head too high	
<ul style="list-style-type: none"><li>● Engine must be cold (room temperature 20°C/68°F)</li><li>● Pull wire off temperature sensor</li><li>● Connect ohmmeter (Resistance approx. 2.5 KΩ)</li></ul>	
Measured resistance is as specified	Ohmmeter shows 0 Ω or ∞ Ω

Exhaust gas recirculates at idle	
<ul style="list-style-type: none"><li>● Switch on ignition</li><li>● Operate throttle valve (EGR valve must click if throttle valve is opened approx. 11° and 75°)</li></ul>	
EGR valve clicks	EGR valve does not click

EGR valve leaks	
<ul style="list-style-type: none"><li>● Run engine at idle</li><li>● Exhaust gas recirculating pipe may not warm up</li></ul>	
Pipe does not warm up	Pipe warms up

Replace temperature sensor




Contact in throttle valve switch does not operate	
<ul style="list-style-type: none"><li>● Pull off connector on EGR valve</li><li>● Connect test light</li><li>● Operate throttle valve (Test light must light up at idle and full throttle position)</li></ul>	
Test light lights up	Test light does not light up

Replace EGR valve

Check wire to throttle valve switch, if OK replace throttle valve switch

Replace EGR valve

(continued from page 33)



Exhaust is being fed back at idling speed	
<ul style="list-style-type: none"><li>● Let engine run at idling speed</li><li>● Pipe between exhaust recirculation valve and intake air distributor should not get hot</li></ul>	
Pipe does not get hot	Pipe gets hot


Idling speed regulator incorrectly adjusted	
Check adjustment and correct if necessary	
Idling still irregular	Idling OK

Injector leaking	
<ul style="list-style-type: none"><li>● Remove injectors but leave them connected to the ring main</li><li>● Pull off wire terminal 1 on coil</li><li>● Operate starter briefly and check if more than two drops leak from each injector per minute</li></ul> Replace leaking injectors	


Contact in throttle valve switch does not operate	
<ul style="list-style-type: none"><li>● Pull off connector on EGR valve</li><li>● Connect test light (with ignition switched on test light must light up)</li></ul>	
Test light lights up	Test light does not light up

Replace EGR valve

Check wire to throttle valve switch, if OK replace throttle valve switch



- Idle speed regulator must be set with engine running
- Engine oil temperature 50° – 70° C (122° – 158° F)
  - Set idle speed to 850 ± 50 rpm
  - Apply parking brake and select a driving range (under this load idle speed must be 700 – 750 rpm and gap a = 0.5 – 1.0 mm (0.02 – 0.04 in.)
  - If necessary adjust gap on push rod (arrow)



Type 2  
– automatic transmission – only

- Test condition:
- Engine warm 50°–70° C (122°–158° F)
  - Tachometer connected
  - Engine running at idling speed

Throttle valve not closing	
Press throttle valve with thumb to see if it is fully closed and watch idling speed	
Idle does not drop	Idle drops


Adjusting screw out of adjustment	
Adjust idle by turning screw	
Correct setting can only be obtained by turning screw fully in	Speed can be adjusted

Auxiliary air regulator not closing	
Block hose between auxiliary air regulator and rubber elbow with a clamp	
Speed does not drop	Speed drops

Throttle valve sticking
<b>Possible troubles:</b> <ul style="list-style-type: none"><li>● Throttle control sticking (accelerator cable, pedal)</li><li>● Throttle shaft stiff in operation</li><li>● Throttle valve switch base plate bent</li><li>● Hose from speed regulator disconnected</li></ul> Type 2 – automatic transmission – only <ul style="list-style-type: none"><li>● Speed regulator incorrectly adjusted</li><li>● Speed regulator defective</li></ul>

go to  
page 31

go to  
page 29



**Test conditions**  
● Idle within tolerances

Engine not running on all cylinders	
Pull off plug connectors one after the other and check if all cylinders are firing	
All cylinders firing	Not running on all cylinders

Valve clearance incorrect	
Check clearance and if necessary correct (engine cold)	
Idling still irregular	Idling OK



Engine drawing in air via crankcase	
<b>Possible causes:</b> <ul style="list-style-type: none"><li>● Oil filler pipe leaking</li><li>● Oil filler cap leaking</li><li>● Dipstick cap leaking</li><li>● Connections of crankcase ventilation</li><li>● Valve cover gasket leaking</li></ul>	
Idling still irregular	Idling OK

Leaks in air intake system	
<b>Possible causes:</b> <ul style="list-style-type: none"><li>● Intake pipes on cylinder head</li><li>● Cold start valve on intake air distributor</li><li>● Connections between throttle valve housing/ intake air distributor</li><li>● Throttle valve shaft</li><li>● Pipe between intake air distributor and exhaust gas recirculation valve</li><li>● Injector seal leaking</li><li>● Hose connections</li></ul>	
Idling still irregular	Idling OK

go to  
page 35

Trouble in ignition distributor or coil	
<ul style="list-style-type: none"><li>● Check distributor cap for:<ul style="list-style-type: none"><li>– dampness, dirt</li><li>– cracks, tracking</li><li>– condition of carbon brush</li></ul></li><li>● Check contact breaker points for gap and pitting</li><li>● Check ignition coil for:<ul style="list-style-type: none"><li>– cracks, tracking</li><li>– ground connection and good wire contacts</li></ul></li></ul>	
No trouble located	Trouble located and corrected; engine now runs smoothly

Ignition wires or plug connectors defective.  
Eliminate defect



Type 1

Type 2

(continued from page 27)


Auxiliary air regulator defective	
<ul style="list-style-type: none"><li>● Pull off connector on auxiliary air regulator</li><li>● Connect test light</li><li>● Light must light up when engine is running</li></ul>	
Test light does not light up	Test light lights up

Replace auxiliary air regulator

**Dead wire:**

- to double relay, terminal 88 c
- to control unit, terminal 34

Repair defect



(continued from page 27)

Deceleration air valve not closing	
Seal hose between deceleration air valve and intake air distributor with a clamp	
Speed does not drop	Speed drops

Hose between pressure regulator and air intake distributor defective or disconnected

