

**Type II
Spare Parts**



Main Group 0



**Jack
Tools
Accessories**


July 1956

MAIN GROUP



Illustration

11	Jack	39
12	Tools	39
16	Accessories	39



Key-No.	Part-No.	Description	Qty.	Type and model
JACK				
1	211 011 031	Jack	1	
TOOLS AND ACCESSORIES				
-	111 012 021	Tool kit	1	
2	211 012 025	Tool kit	1	
-	N 30 054 1	Wrench 8×12	1	
-	N 30 059 1	Wrench 17×19	1	
-	N 30 002 1	Pliers – Combination	1	
-	N 30 053 1	Wrench 8×9	1	
-	111 012 201	Socket wrench –	1	
		Sparking plug, wheel bolt and jack		
-	111 012 203	Socket wrench – Sparking plug	1	
-	111 012 221	Handle (mandrel) – Socket wrench (length 400 mm.)	1	
-	111 012 231	Ring wrench 36 mm.	1	
-	111 012 265	Speed handle – Wheel bolt	1	
-	111 012 269	Wrench, ball-pointed, 14 mm.	1	
3	211 012 301	Starting handle	1	
4	111 012 605	Gauge – Tire pressure	1	
5	111 012 625	Inspection lamp	1	
6	111 012 627	Cable plug – Inspection lamp	1	
-	211 016 015	Sleeping installation for Micro Bus	1	221-244
7	111 016 131	Cigar lighter, black	×	
-	113 016 131	Cigar lighter, ivory	×	

Key-No.	Part-No.	Description	Qty.	Type and model
8	111 016 141	Coil – Cigar lighter	×	
–	211 016 251	Draft excluder – Clutch and brake pedals up to chassis No. 20 – 117 901	4	
–	211 016 253	Draft excluder – Accelerator pedal up to chassis No. 20 – 117 901	2	