


MAIN GROUP 0

ACCESSORIES

	Illustration
11 Jack	65
12 Tools	65



MAIN GROUP 0

ACCESSORIES

Key	Part No.	Description	Qty.	Type and model
JACK				
1	111 011 031 C	Jack without handle	1	
TOOLS				
2	311 012 021 C	Tool kit	1	
3	311 012 205 A	Socket wrench – Spark plug and wheel bolts	1	
4	111 012 221	Tommy bar 400 mm – Socket wrench and jack	1	
5	343 012 221	Tommy bar 190 mm – Socket wrench	1	
6	111 012 235 B	Socket wrench 13	1	315-318, 365-368
7	311 012 243	Hub cap removal tool	1	
8	111 012 255	Screwdriver – Slotted and phillips hd. screws	1	
9	N 30 002 1	Combination pliers to Ch. No. 311 2500 000	1	
10	N 30 055 1	Wrench 8 x 13	1	
11	N 30 080 1	Wrench 27	1	
12	311 012 281	Bracket left – Licence plate front to Ch. No. 483 592	1	
13	311 012 282	Bracket right – Licence plate front to Ch. No. 483 592	1	
14	111 012 361	Pump for housing sealing compound D 3	1	
15	311 035 281 C	* Connector – Ignition distributor cap	5	M 236
STICKERS				
-	311 000 257	Sticker 'Tire pressures' to Ch. No. 319 500 000	1	311-318
-	311 000 257 B	Sticker "Tire pressures" from Ch. No. 310 2000 001	1	311-318
-	361 000 257 B	Sticker 'Tire pressures' to Ch. No. 369 500 000	1	361-368
-	361 000 257 H	Sticker "Tire pressures" from Ch. No. 360 2000 001	1	361-368
-	361 000 257 C	Sticker 'Tire pressures' to Ch. No. 366 500 000	1	M 267
-	361 000 257 J	Sticker "Tire pressures" from Ch. No. 367 000 001	1	M 263
-	311 000 259	Sticker 'Super/Premium' from Ch. No. 221 975 to 315 220 883	1	311-314, 343-346,
-	113 000 269 F	* Sticker 'shift positions'	1	M 239, M 242, M 257
-	311 000 269 A	Sticker 'shift positions'	1	M 249
-	211 000 285	Sticker 'Battery'	1	
-	111 100 173	* Sticker 'Firing point 0°'	1	M 236

-	111 100 173 A	Sticker 'Firing point 7.5'	1
-	022 100 175	Sticker "Valve clearance" from Ch. No. 315 000 001	1
-	311 100 175	Sticker 'Valve clearance' to Ch. No. 483 592	1
-	311 100 177	Clip 'Valve clearance' to Ch. No. 483 592	X
-	111 900 275	Sticker '12 V'	1