

**Type 2  
1968 1969**

Owner: \_\_\_\_\_

Page 1 of 2

Date: \_\_\_\_\_

<b>Fuse Number of Electrical Components (sorted by fuse box number)</b>	<b>1 9 6 8 - 6 9</b>	<b>M Y  B U S</b>
Horn	1	
Stop / Brake Lights	1	
Turn Signals - all	1	
Warning Light - brake	1	
Rear Window Defogger (switch current)	2	
Windshield Wipers	2	
Headlights: High Beam - left	3	
Headlights: High Beam Indicator Light	3	
Headlights: High Beam - right	4	
Headlights: Low Beam - left	5	
Headlights: Low Beam - right	6	
License Plate Light	7	
Parking Lights	7	
Tail Light - right	7	
Tail Light - left	8	
Emergency Flasher System	9	
Interior Light - front	9	
Interior Light - rear	9	

**Type 2  
1968 1969**

Owner: \_\_\_\_\_

Date: \_\_\_\_\_

<b>Fuse Number of Electrical Components (sorted by fuse box number)</b>	<b>1 9 6 8 - 6 9</b>	<b>M Y  B U S</b>
Unassigned (accessory)	10	
Auxiliary Heater (switch current)		
Backup Lights (automatic transmission only)		
Buzzer Alarm		
Fuel Gauge		
Kickdown (automatic transmission - except 1976)		
Side Marker Light - left rear		
Side Marker Light - right rear		
Side Marker Lights - front		
Warning Light - generator or alternator		
Warning Light - oil pressure		

Notes: \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_

**FUSE BOX**

O (circled) = actual fuse amperage in bus

1	2	3	4	5	6	7	8	9	10	11	12
8 or 16 amp	8 or 16 amp	8 or 16 amp	8 or 16 amp	8 or 16 amp	8 or 16 amp	8 or 16 amp	8 or 16 amp	8 or 16 amp	8 or 16 amp	8 or 16 amp	8 or 16 amp

**Type 2  
1970**

Owner: \_\_\_\_\_

Page 1 of 2

Date: \_\_\_\_\_

<b>Fuse Number of Electrical Components (sorted by fuse box number)</b>	<b>1 9 7 0</b>	<b>M Y B u s</b>
Interior Light - rear	1	
Buzzer Alarm	2	
Emergency Flasher System	2	
Interior Light - front	2	
Horn	3	
Rear Window Defogger (switch current)	3	
Stop / Brake Lights	3	
Warning Light - brake	3	
Fuel Gauge	4	
Turn Signals - all	4	
Warning Light - generator or alternator	4	
Warning Light - oil pressure	4	
Windshield Wipers	5	
Unassigned (accessory)	6	
Headlights: High Beam - left	7	
Headlights: High Beam Indicator Light	7	
Headlights: High Beam - right	8	
Headlights: Low Beam - left	9	

**Type 2  
1970**

Owner: \_\_\_\_\_

Date: \_\_\_\_\_

<b>Fuse Number of Electrical Components (sorted by fuse box number)</b>	<b>1 9 7 0</b>	<b>M Y B U S</b>
Headlights: Low Beam - right	10	
Side Marker Light - left rear	11	
Tail Light - left	11	
License Plate Light	12	
Parking Lights	12	
Side Marker Light - right rear	12	
Tail Light - right	12	
Auxiliary Heater (switch current)		
Backup Lights (automatic transmission only)		
Kickdown (automatic transmission - except 1976)		
Side Marker Lights - front		

Notes: \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_

**FUSE BOX**

O (circled) = actual fuse amperage in bus

1	2	3	4	5	6	7	8	9	10	11	12
8	8	8	8	8	8	8	8	8	8	8	8
or	or	or	or	or	or	or	or	or	or	or	or
16	16	16	16	16	16	16	16	16	16	16	16
amp	amp	amp	amp	amp	amp	amp	amp	amp	amp	amp	amp

**Type 2  
1971**

Owner: \_\_\_\_\_

Page 1 of 2

Date: \_\_\_\_\_

<b>Fuse Number of Electrical Components (sorted by fuse box number)</b>	<b>1 9 7 1</b>	<b>M Y B u s</b>
License Plate Light	1	
Parking Lights	1	
Side Marker Light - right rear	1	
Tail Light - right	1	
Side Marker Light - left rear	2	
Tail Light - left	2	
Headlights: Low Beam - right	3	
Headlights: Low Beam - left	4	
Headlights: High Beam - right	5	
Headlights: High Beam - left	6	
Headlights: High Beam Indicator Light	6	
Unassigned (accessory)	7	
Emergency Flasher System	8	
Interior Light - front	8	
Buzzer Alarm	9	
Interior Light - rear	9	
Auxiliary Heater (switch current)	9/11	
Horn	10	

**Type 2  
1971**

Owner: \_\_\_\_\_

Date: \_\_\_\_\_

<b>Fuse Number of Electrical Components (sorted by fuse box number)</b>	<b>1 9 7 1</b>	<b>M Y B u s</b>
Rear Window Defogger (switch current)	10	
Stop / Brake Lights	10	
Windshield Wipers	11	
Fuel Gauge	12	
Turn Signals - all	12	
Warning Light - brake	12	
Warning Light - generator or alternator	12	
Warning Light - oil pressure	12	
Backup Lights (automatic transmission only)		
Kickdown (automatic transmission - except 1976)		
Side Marker Lights - front		

Notes: \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_

**FUSE BOX**

O (circled) = actual fuse amperage in bus

1	2	3	4	5	6	7	8	9	10	11	12
8 or 16 amp	8 or 16 amp	8 or 16 amp	8 or 16 amp	8 or 16 amp	8 or 16 amp	8 or 16 amp	8 or 16 amp	8 or 16 amp	8 or 16 amp	8 or 16 amp	8 or 16 amp

**Type 2  
1972**

Owner: \_\_\_\_\_

Page 1 of 2

Date: \_\_\_\_\_

<b>Fuse Number of Electrical Components (sorted by fuse box number)</b>	<b>1 9 7 2</b>	<b>M Y B u s</b>
Side Marker Light - left rear	1	
Tail Light - left	1	
License Plate Light	2	
Parking Lights	2	
Side Marker Light - right rear	2	
Tail Light - right	2	
Headlights: Low Beam - right	3	
Headlights: Low Beam - left	4	
Headlights: High Beam - right	5	
Headlights: High Beam - left	6	
Headlights: High Beam Indicator Light	6	
Unassigned (accessory)	7	
Emergency Flasher System	8	
Interior Light - front	8	
Buzzer Alarm	9	
Interior Light - rear	9	
Auxiliary Heater (switch current)	9/10	
Rear Window Defogger (switch current)	10	

**Type 2  
1972**

Owner: \_\_\_\_\_

Date: \_\_\_\_\_

<b>Fuse Number of Electrical Components (sorted by fuse box number)</b>	<b>1 9 7 2</b>	<b>M Y B U S</b>
Windshield Wipers	10	
Fuel Gauge	11	
Turn Signals - all	11	
Warning Light - generator or alternator	11	
Warning Light - oil pressure	11	
Horn	12	
Stop / Brake Lights	12	
Warning Light - brake	12	
Backup Lights (automatic transmission only)		
Kickdown (automatic transmission - except 1976)		
Side Marker Lights - front		

Notes: \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_

**FUSE BOX**

O (circled) = actual fuse amperage in bus

1	2	3	4	5	6	7	8	9	10	11	12
8	8	8	8	8	8	8	8	8	8	8	8
or	or	or	or	or	or	or	or	or	or	or	or
16	16	16	16	16	16	16	16	16	16	16	16
amp	amp	amp	amp	amp	amp	amp	amp	amp	amp	amp	amp



**Type 2  
1973**

Owner: \_\_\_\_\_

Date: \_\_\_\_\_

<b>Fuse Number of Electrical Components (sorted by fuse box number)</b>	<b>1 9 7 3</b>	<b>M Y B U S</b>
Side Marker Light - left rear	1	
Tail Light - left	1	
License Plate Light	2	
Parking Lights	2	
Side Marker Lights - front	2	
Side Marker Light - right rear	2	
Tail Light - right	2	
Headlights: Low Beam - left	3	
Headlights: Low Beam - right	4	
Headlights: High Beam - left	5	
Headlights: High Beam Indicator Light	5	
Headlights: High Beam - right	6	
Unassigned (accessory)	7	
Interior Light - front	8	
Emergency Flasher System	8	
Buzzer Alarm	9	
Interior Light - rear	9	
Auxiliary Heater (switch current)	9/10	

**Type 2  
1973**

Owner: \_\_\_\_\_

Date: \_\_\_\_\_

<b>Fuse Number of Electrical Components (sorted by fuse box number)</b>	<b>1 9 7 3</b>	<b>M Y B U S</b>
Rear Window Defogger (switch current)	10	
Windshield Wipers	10	
Backup Lights (automatic transmission only)	11	
Fuel Gauge	11	
Kickdown (automatic transmission - except 1976)	11	
Turn Signals - all	11	
Warning Light - generator or alternator	11	
Warning Light - oil pressure	11	
Horn	12	
Stop / Brake Lights	12	
Warning Light - brake	12	

Notes: \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_

**FUSE BOX**

O (circled) = actual fuse amperage in bus

1	2	3	4	5	6	7	8	9	10	11	12
8	8	8	8	8	8	8	8	8	8	8	8
or	or	or	or	or	or	or	or	or	or	or	or
16	16	16	16	16	16	16	16	16	16	16	16
amp	amp	amp	amp	amp	amp	amp	amp	amp	amp	amp	amp

**Type 2  
1974**

Owner: \_\_\_\_\_

Page 1 of 2

Date: \_\_\_\_\_

<b>Fuse Number of Electrical Components (sorted by fuse box number)</b>	<b>1 9 7 4</b>	<b>M Y B U S</b>
Side Marker Light - left rear	1	
Tail Light - left	1	
License Plate Light	2	
Parking Lights	2	
Side Marker Lights - front	2	
Side Marker Light - right rear	2	
Tail Light - right	2	
Headlights: Low Beam - left	3	
Headlights: Low Beam - right	4	
Headlights: High Beam - left	5	
Headlights: High Beam Indicator Light	5	
Headlights: High Beam - right	6	
Unassigned (accessory)	7	
Emergency Flasher System	8	
Interior Light - front	8	
Buzzer Alarm	9	
Interior Light - rear	9	
Auxiliary Heater (switch current)	9/10	

**Type 2  
1974**

Owner: \_\_\_\_\_

Date: \_\_\_\_\_

<b>Fuse Number of Electrical Components (sorted by fuse box number)</b>	<b>1 9 7 4</b>	<b>M Y B U S</b>
Rear Window Defogger (switch current)	10	
Windshield Wipers	10	
Backup Lights (automatic transmission only)	11	
Fuel Gauge	11	
Kickdown (automatic transmission - except 1976)	11	
Turn Signals - all	11	
Warning Light - generator or alternator	11	
Warning Light - oil pressure	11	
Horn	12	
Stop / Brake Lights	12	
Warning Light - brake	12	

Notes: \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_

**FUSE BOX**

O (circled) = actual fuse amperage in bus

1	2	3	4	5	6	7	8	9	10	11	12
8	8	8	8	8	8	8	8	8	8	8	8
or	or	or	or	or	or	or	or	or	or	or	or
16	16	16	16	16	16	16	16	16	16	16	16
amp	amp	amp	amp	amp	amp	amp	amp	amp	amp	amp	amp

**Type 2  
1975-1979**

Owner: \_\_\_\_\_

Page 1 of 2

Date: \_\_\_\_\_

<b>Fuse Number of Electrical Components (sorted by fuse box number)</b>	<b>1 9 7 5 - 7 9</b>	<b>M Y  B U S</b>
Side Marker Light - left rear	1	
Tail Light - left	1	
License Plate Light	2	
Parking Lights	2	
Side Marker Lights - front	2	
Side Marker Light - right rear	2	
Tail Light - right	2	
Headlights: Low Beam - left	3	
Headlights: Low Beam - right	4	
Headlights: High Beam - left	5	
Headlights: High Beam Indicator Light	5	
Headlights: High Beam - right	6	
Unassigned (accessory)	7	
Emergency Flasher System	8	
Interior Light - front	8	
Interior Light - rear	8	
Buzzer Alarm	9	
Auxiliary Heater (switch current)	9/10	

**Type 2  
1975-1979**

Owner: \_\_\_\_\_

Date: \_\_\_\_\_

<b>Fuse Number of Electrical Components (sorted by fuse box number)</b>	<b>1 9 7 5 - 7 9</b>	<b>M Y  B U S</b>
Rear Window Defogger (switch current)	10	
Windshield Wipers	10	
Backup Lights (automatic transmission only)	11	
Fuel Gauge	11	
Kickdown (automatic transmission - except 1976)	11	
Turn Signals - all	11	
Warning Light - generator or alternator	11	
Warning Light - oil pressure	11	
Horn	12	
Stop / Brake Lights	12	
Warning Light - brake	12	

Notes: \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_

**FUSE BOX**

O (circled) = actual fuse amperage in bus

1	2	3	4	5	6	7	8	9	10	11	12
8	8	8	8	8	8	8	8	8	8	8	8
or	or	or	or	or	or	or	or	or	or	or	or
16	16	16	16	16	16	16	16	16	16	16	16
amp	amp	amp	amp	amp	amp	amp	amp	amp	amp	amp	amp